2020 Extra Class Question Pool

F1: COMMISSION RULES

	E1: COMMISSION RULES
	rating Standards: frequency privileges; automatic message forwarding; stations aboard ships or aircraft; power riction on 630 and 2200 meter bands
: :	hich of the following carrier frequencies is illegal for LSB AFSK emissions on the 17 meter band RTTY and ata segment of 18.068 to 18.110 MHz?
	A 18.068 MHz
d	/hen using a transceiver that displays the carrier frequency of phone signals, which of the following isplayed frequencies represents the lowest frequency at which a properly adjusted LSB emission will be otally within the band?
	3 kHz above the lower band edge
	/hat is the maximum legal carrier frequency on the 20 meter band for transmitting USB AFSK digital signals aving a 1 kHz bandwidth?
	C 14.149 MHz
	ith your transceiver displaying the carrier frequency of phone signals, you hear a DX station calling CQ on .601 MHz LSB. Is it legal to return the call using lower sideband on the same frequency?
	No, the sideband will extend beyond the edge of the phone band segment
E1A05 V	hat is the maximum power output permitted on the 60 meter band?
	C 100 watts PEP effective radiated power relative to the gain of a half-wave dipole
E1A06 V	here must the carrier frequency of a CW signal be set to comply with FCC rules for 60 meter operation?
i	B At the center frequency of the channel
[
	/hat is the maximum power permitted on the 2200 meter band?
	C 1 watt EIRP (Equivalent isotropic radiated power)
	f a station in a message forwarding system inadvertently forwards a message that is in violation of FCC ules, who is primarily accountable for the rules violation?
	B The control operator of the originating station
	/hat action or actions should you take if your digital message forwarding station inadvertently forwards a communication that violates FCC rules?
	A Discontinue forwarding the communication as soon as you become aware of it
	f an amateur station is installed aboard a ship or aircraft, what condition must be met before the station is perated?
	A Its operation must be approved by the master of the ship or the pilot in command of the aircraft
1 1	hich of the following describes authorization or licensing required when operating an amateur station board a U.Sregistered vessel in international waters?
	Any FCC-issued amateur license
E1A12 V	hat special operating frequency restrictions are imposed on slow scan TV transmissions?
	C They are restricted to phone band segments
	ho must be in physical control of the station apparatus of an amateur station aboard any vessel or craft nat is documented or registered in the United States?
	Any person holding an FCC issued amateur license or who is authorized for alien reciprocal operation
E1A14 E	xcept in some parts of Alaska, what is the maximum power permitted on the 630 meter band?
	D 5 watts EIRP

a		restrictions and special operations: restrictions on station location; general operating restrictions; spurious emission a structure restrictions; RACES operations
E1B01	Whi	ch of the following constitutes a spurious emission?
	D	An emission outside the signal's necessary bandwidth that can be reduced or eliminated without affecting the information transmitted
E1B02		ch of the following is an acceptable bandwidth for Digital Radio Mondiale (DRM) based voice or SSTV all transmissions made on the HF amateur bands?
	_	3 kHz
E1B03	With	nin what distance must an amateur station protect an FCC monitoring facility from harmful interference?
	Α	1 mile
E1B04	1	t must be done before placing an amateur station within an officially designated wilderness area or life preserve, or an area listed in the National Register of Historic Places?
	С	An Environmental Assessment must be submitted to the FCC
E1B05	Wha	t is the National Radio Quiet Zone?
	С	An area surrounding the National Radio Astronomy Observatory
E1B06	1	ch of the following additional rules apply if you are installing an amateur station antenna at a site at or a public use airport?
	A	You may have to notify the Federal Aviation Administration and register it with the FCC as required by Part 17 of the FCC rules
E1B07	To v	hat type of regulations does PRB-1 apply?
	С	State and local zoning
E1B08		t limitations may the FCC place on an amateur station if its signal causes interference to domestic dcast reception, assuming that the receivers involved are of good engineering design?
	D	The amateur station must avoid transmitting during certain hours on frequencies that cause the interference
E1B09	Whi	ch amateur stations may be operated under RACES rules?
	С	Any FCC-licensed amateur station certified by the responsible civil defense organization for th area served
E1B10	Wha	t frequencies are authorized to an amateur station operating under RACES rules?
	Α	All amateur service frequencies authorized to the control operator
E1B11	Wha	t does PRB-1 require of regulations affecting amateur radio?
	В	Reasonable accommodations of amateur radio must be made
E1B12		t must the control operator of a repeater operating in the 70 cm band do if a radiolocation system
	ехр	criences interference from that repeater? Cease operation or make changes to the repeater to mitigate the interference

		ies; spurious emission standards; HF modulation index limit; bandwidth definition
E1C01	Wha	at is the maximum bandwidth for a data emission on 60 meters?
	D	2.8 kHz
E1C02	Whi	ch of the following types of communications may be transmitted to amateur stations in foreign countries
	C	Communications incidental to the purpose of the amateur service and remarks of a personal nature
E1C03	:	v do the control operator responsibilities of a station under automatic control differ from one under local trol?
	В	Under automatic control the control operator is not required to be present at the control point
E1C04		at is meant by IARP? An international amateur radio permit that allows U.S. amateurs to operate in certain countrie
	A	of the Americas
E1C05	Whe	en may an automatically controlled station originate third party communications?
	Α	Never
E1C06	Whi	ch of the following is required in order to operate in accordance with CEPT rules in foreign countries
LICOU	:	ere permitted?
	С	You must bring a copy of FCC Public Notice DA 16-1048
E1C07	At v	what level below a signal's mean power level is its bandwidth determined according to FCC rules?
	 D	26 dB
		5
E1C08	:	at is the maximum permissible duration of a remotely controlled station's transmissions if its control link functions?
	В	3 minutes
E1C09	•	at is the highest modulation index permitted at the highest modulation frequency for angle modulation by 29.0 MHz?
	В	1.0
E1C10	•	at is the permitted mean power of any spurious emission relative to the mean power of the fundamental
		ssion from a station transmitter or external RF amplifier installed after January 1, 2003 and transmitting I frequency below 30 MHz?
		At least 43 dB below
	···]	
E1C11	1	ch of the following operating arrangements allows an FCC-licensed U.S. citizen to operate in many opean countries, and alien amateurs from many European countries to operate in the U.S.?
		CEPT agreement
E1C12	0-	what parties of the 620 meter hand are phone emissions resmitted?
E1C12	D D	what portion of the 630 meter band are phone emissions permitted? The entire band
		THE CHUIC VAILU
E1C13	!	at notifications must be given before transmitting on the 630 meter or 2200 meter bands?
	С	Operators must inform the Utilities Telecom Council of their call sign and coordinates of the station
E1C14		long must an operator wait after filing a notification with the Utilities Telecom Commission before
E1C14		o long must an operator wait after filing a notification with the Utilities Telecom Commission before rating on the 2200 meter or 630 meter band? Operators may operate after 30 days, providing they have not been told that their station is

	Amateur space and Earth stations; telemetry and telecommand rules; identification of balloon transmissions; one-way communications
E1D01	What is the definition of telemetry? A One-way transmission of measurements at a distance from the measuring instrument
	A One-way transmission of measurements at a distance from the measuring instrument
E1D02	Which of the following may transmit special codes intended to obscure the meaning of messages? A Telecommand signals from a space telecommand station
E1D03	What is a space telecommand station?
i	B An amateur station that transmits communications to initiate, modify or terminate functions of a space station
E1D04	Which of the following is required in the identification transmissions from a balloon-borne telemetry station?
LIDOI	A Call sign
E1D05	What must be posted at the station location of a station being operated by telecommand on or within 50 km of the earth's surface?
	D All these choices are correct
E1D06	What is the maximum associated to a sociated and a sociated associated associ
E1D06	What is the maximum permitted transmitter output power when operating a model craft by telecommand? A 1 watt
E1D07	Which HF amateur bands have frequencies authorized for space stations?
<u> </u>	A Only the 40, 20, 17, 15, 12, and 10 meter bands
E1D08	Which VHF amateur bands have frequencies authorized for space stations?
	D 2 meters
F1500	
E1D09	
	B 70 cm and 13 cm
E1D10	Which amateur stations are eligible to be telecommand stations of space stations (subject to the privileges of
	the class of operator license held by the control operator of the station)?
	B Any amateur station so designated by the space station licensee
E1D11	Which amateur stations are eligible to operate as Earth stations?
	D Any amateur station, subject to the privileges of the class of operator license held by the control operator
E1D12	Which of the following amateur stations may transmit one-way communications?
LIDIZ	A A space station, beacon station, or telecommand station

	<i>,</i>	documentation requirements
E1E01	For v	which types of out-of-pocket expenses do the Part 97 rules state that VEs and VECs may be reimbursed
	A	Preparing, processing, administering, and coordinating an examination for an amateur radio operator license
E1E02	.i	does Part 97 task with maintaining the pools of questions for all U.S. amateur license examinations?
	С	The VECs
E1E03	Wha	t is a Volunteer Examiner Coordinator?
	С	An organization that has entered into an agreement with the FCC to coordinate, prepare, and administer amateur operator license examinations
E1E04	Whi	ch of the following best describes the Volunteer Examiner accreditation process?
	D	The procedure by which a VEC confirms that the VE applicant meets FCC requirements to servas an examiner
E1E05	Wha	t is the minimum passing score on all amateur operator license examinations?
	В	Minimum passing score of 74%
E1E06	.1	is responsible for the proper conduct and necessary supervision during an amateur operator license
		nination session?
	С	Each administering VE
E1E07		t should a VE do if a candidate fails to comply with the examiner's instructions during an amateur rator license examination?
	В	Immediately terminate the candidate's examination
E1E08	To w	hich of the following examinees may a VE not administer an examination?
	C	Relatives of the VE as listed in the FCC rules
E1E09	Wha	t may be the penalty for a VE who fraudulently administers or certifies an examination?
	A	Revocation of the VE's amateur station license grant and the suspension of the VE's amateur operator license grant
E1E10	:	t must the administering VEs do after the administration of a successful examination for an amateur ator license?
	С	They must submit the application document to the coordinating VEC according to the coordinating VEC instructions
E1E11	1	t must the VE team do if an examinee scores a passing grade on all examination elements needed for a ade or new license?
	В	Three VEs must certify that the examinee is qualified for the license grant and that they have complied with the administering VE requirements

	On v	what frequencies are spread spectrum transmissions permitted?
	В	Only on amateur frequencies above 222 MHz
E1F02		at privileges are authorized in the U.S. to persons holding an amateur service license granted by the ernment of Canada?
	С	The operating terms and conditions of the Canadian amateur service license, not to exceed U Amateur Extra Class license privileges
E1F03		er what circumstances may a dealer sell an external RF power amplifier capable of operation below 14- if it has not been granted FCC certification?
	A	It was purchased in used condition from an amateur operator and is sold to another amateur operator for use at that operator's station
E1F04	Whi	ch of the following geographic descriptions approximately describes "Line A"?
L11 U7	:	A line roughly parallel to and south of the border between the U.S. and Canada
	con D	iguous 48 states and north of Line A? 420 MHz - 430 MHz
	7	
E1F06	:	er what circumstances might the FCC issue a Special Temporary Authority (STA) to an amateur station? To provide for experimental amateur communications
E1F07	Whe	en may an amateur station send a message to a business?
	D	When neither the amateur nor his or her employer has a pecuniary interest in the communications
E1F08	Whi	ch of the following types of amateur station communications are prohibited?
	A	Communications transmitted for hire or material compensation, except as otherwise provided in the rules
E1F09	Whi	ch of the following conditions apply when transmitting spread spectrum emissions?
E1F09	Whi D	ch of the following conditions apply when transmitting spread spectrum emissions? All these choices are correct
	.i D	
	.i D	All these choices are correct
	D Who B Whi	All these choices are correct may be the control operator of an auxiliary station?

	E2: OPERATING PROCEDURES
	Amateur radio in space: amateur satellites; orbital mechanics; frequencies and modes; satellite hardware; satellite operations
E2A01	What is the direction of an ascending pass for an amateur satellite?
	C From south to north
E2A02	Which of the following occurs when a satellite is using an inverted linear transponder?
	D All these choices are correct
E2A03	How is the signal inverted by an inverting linear transponder?
	D The signal is passed through a mixer and the difference rather than the sum is transmitted
E2A04	What is meant by the term "mode" as applied to an amateur radio satellite?
	B The satellite's uplink and downlink frequency bands
E2A05	What do the letters in a satellite's mode designator specify?
	D The uplink and downlink frequency ranges
E2A06	What are Keplerian elements?
	A Parameters that define the orbit of a satellite
E2A07	Which of the following types of signals can be relayed through a linear transponder?
	D All these choices are correct
E2A08	Why should effective radiated power to a satellite that uses a linear transponder be limited?
	B To avoid reducing the downlink power to all other users
E2A09	What do the terms "L band" and "S band" specify regarding satellite communications?
	A The 23 centimeter and 13 centimeter bands
E2A10	What type of satellite appears to stay in one position in the sky?
LZAIO	B Geostationary
F2A11	What type of automa can be used to minimize the effects of only modulation and Eavaday votation?
E2A11	What type of antenna can be used to minimize the effects of spin modulation and Faraday rotation? B A circularly polarized antenna
F2442	
E2A12	What is the purpose of digital store-and-forward functions on an amateur radio satellite? C To store digital messages in the satellite for later download by other stations
E2A13	Which of the following techniques is normally used by low Earth orbiting digital satellites to relay messag around the world?
	B Store-and-forward

2B01	How	many times per second is a new frame transmitted in a fast-scan (NTSC) television system?
	Α	30
2B02	Ном	many horizontal lines make up a fast-scan (NTSC) television frame?
	С	525
E2B03	How	is an interlaced scanning pattern generated in a fast-scan (NTSC) television system?
	D	By scanning odd numbered lines in one field and even numbered lines in the next
E2B04	How	is color information sent in analog SSTV?
)	Color lines are sent sequentially
	\A/L-	ab of the following describes the use of vectorial sideband in such a fact seen TV towns with the Co.
2B05		ch of the following describes the use of vestigial sideband in analog fast-scan TV transmissions?
	С	Vestigial sideband reduces bandwidth while allowing for simple video detector circuitry
E2B06	Wha	it is vestigial sideband modulation?
	Α	Amplitude modulation in which one complete sideband and a portion of the other are transmitted
2B07	Wha	It is the name of the signal component that carries color information in NTSC video?
	В	Chroma
E2B08	Wha ban	It technique allows commercial analog TV receivers to be used for fast-scan TV operations on the 70 cm
	Α	Transmitting on channels shared with cable TV
E2B09		It hardware, other than a receiver with SSB capability and a suitable computer, is needed to decode SST g Digital Radio Mondiale (DRM)?
		No other hardware is needed
		It aspect of an analog slow-scan television signal encodes the brightness of the picture?
E2B10	Wha	c aspect of an analog slow scall television signal encodes the singlificace of the picture.
E2B10		Tone frequency
	Α	Tone frequency
E2B10 E2B11	A Wha	Tone frequency It is the function of the Vertical Interval Signaling (VIS) code sent as part of an SSTV transmission?
	A Wha	Tone frequency
	A Wha B	Tone frequency It is the function of the Vertical Interval Signaling (VIS) code sent as part of an SSTV transmission?

E2C01	Wha	at indicator is required to be used by U.Slicensed operators when operating a station via remote control
	i	the remote transmitter is located in the U.S.?
	D	No additional indicator is required
E2C02	Whi	ch of the following best describes the term "self-spotting" in connection with HF contest operating?
	Α	The often-prohibited practice of posting one's own call sign and frequency on a spotting network
E2C03		n which of the following bands is amateur radio contesting generally excluded? 30 meters
E2C04	Whi	ch of the following frequencies are sometimes used for amateur radio mesh networks?
	В	Frequencies shared with various unlicensed wireless data services
F2C05	Wha	at is the function of a DX QSL Manager?
		To handle the receiving and sending of confirmation cards for a DX station
E2C06	:	ing a VHF/UHF contest, in which band segment would you expect to find the highest level of SSB or CW vity?
	С	In the weak signal segment of the band, with most of the activity near the calling frequency
E2C07	Wha	at is the Cabrillo format?
	Α	A standard for submission of electronic contest logs
E2C08	Whi	ch of the following contacts may be confirmed through the U.S. QSL bureau system?
	В	Contacts between a U.S. station and a non-U.S. station
E2C09	Wha	at type of equipment is commonly used to implement an amateur radio mesh network?
	С	A wireless router running custom firmware
E2C10	Why	might a DX station state that they are listening on another frequency?
	D	All these choices are correct
E2C11	:	should you generally identify your station when attempting to contact a DX station during a contest or i
	A	Send your full call sign once or twice
E2C12	Wha	nt technique do individual nodes use to form a mesh network?

E2D01	Whi	ch of the following digital modes is designed for meteor scatter communications?
		MSK144
	_	
E2D02	Whi	ch of the following is a good technique for making meteor scatter contacts?
	D	All these choices are correct
E2D03	Whi	ch of the following digital modes is especially useful for EME communications?
	D	JT65
2D04	Wha	t technology is used to track, in real time, balloons carrying amateur radio transmitters?
	С	APRS
2D05	Wha	t is one advantage of the JT65 mode?
	В	The ability to decode signals which have a very low signal-to-noise ratio
2D06	Whi	ch of the following describes a method of establishing EME contacts?
	Α	Time synchronous transmissions alternately from each station
	Α	Time synchronous transmissions alternately from each station
E2D07		Time synchronous transmissions alternately from each station t digital protocol is used by APRS?
E2D07	Wha	
	Wha C	at digital protocol is used by APRS? AX.25
	Wha C Wha	t digital protocol is used by APRS? AX.25 It type of packet frame is used to transmit APRS beacon data?
	Wha C Wha	at digital protocol is used by APRS? AX.25
E2D08	Wha C Wha A	t digital protocol is used by APRS? AX.25 It type of packet frame is used to transmit APRS beacon data?
E2D08	Wha C Wha A	t digital protocol is used by APRS? AX.25 It type of packet frame is used to transmit APRS beacon data? Unnumbered Information
E2D08	Wha C Wha A	at digital protocol is used by APRS? AX.25 AX type of packet frame is used to transmit APRS beacon data? Unnumbered Information t type of modulation is used for JT65 contacts? Multi-tone AFSK
E2D08 E2D09	Wha C Wha A	AX.25 It type of packet frame is used to transmit APRS beacon data? Unnumbered Information It type of modulation is used for JT65 contacts?
E2D08	Wha A Wha A	at digital protocol is used by APRS? AX.25 AX type of packet frame is used to transmit APRS beacon data? Unnumbered Information t type of modulation is used for JT65 contacts? Multi-tone AFSK
E2D07 E2D08 E2D09 E2D10	Wha C Wha A Wha A	AX.25 It type of packet frame is used to transmit APRS beacon data? Unnumbered Information It type of modulation is used for JT65 contacts? Multi-tone AFSK I can an APRS station be used to help support a public service communications activity? An APRS station with a Global Positioning System unit can automatically transmit informatio

E2E01	W/h:	ch of the following types of modulation is common for data emissions below 30 MHz?
	WIII B	FSK
	ь	FJN
E2E02	Wh:	at do the letters FEC mean as they relate to digital operation?
LZLUZ		Forward Error Correction
E2E03	Hov	v is the timing of FT4 contacts organized?
	C	Alternating transmissions at 7.5 second intervals
	Ū	
E2E04	Wha	at is indicated when one of the ellipses in an FSK crossed-ellipse display suddenly disappears?
	Α	Selective fading has occurred
E2E05	Whi	ch of these digital modes does not support keyboard-to-keyboard operation?
	Α	PACTOR
E2E06	Wha	at is the most common data rate used for HF packet?
	С	300 baud
E2E07	1	ch of the following is a possible reason that attempts to initiate contact with a digital station on a clear
	тгес	uency are unsuccessful?
	D	All those sheises are servest
		All these choices are correct
F2F08		
E2E08	Whi	ch of the following HF digital modes can be used to transfer binary files?
E2E08		
E2E08	Whi B	ch of the following HF digital modes can be used to transfer binary files?
	Whi B Whi	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency?
	Whi B	ch of the following HF digital modes can be used to transfer binary files? PACTOR
	Whi B Whi D	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency?
E2E09	Whi B Whi D	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31
E2E09	Whi B Whi D	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth?
E2E09	Whi B Whi D Whi	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth?
E2E09	Whi B Whi D Whi	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth? PSK31 at is the difference between direct FSK and audio FSK? Direct FSK applies the data signal to the transmitter VFO, while AFSK transmits tones via
E2E09	Whi B Whi D Whi C	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth? PSK31 at is the difference between direct FSK and audio FSK?
E2E09 E2E10 E2E11	Whi D Whi C Wha	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth? PSK31 at is the difference between direct FSK and audio FSK? Direct FSK applies the data signal to the transmitter VFO, while AFSK transmits tones via phone
E2E09	Whi B Whi C Whi A	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth? PSK31 at is the difference between direct FSK and audio FSK? Direct FSK applies the data signal to the transmitter VFO, while AFSK transmits tones via phone
E2E09 E2E10 E2E11	Whi B Whi C Whi A	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth? PSK31 at is the difference between direct FSK and audio FSK? Direct FSK applies the data signal to the transmitter VFO, while AFSK transmits tones via phone of do ALE stations establish contact? ALE constantly scans a list of frequencies, activating the radio when the designated call sign is
E2E09 E2E10 E2E11	Whi B Whi C Whi A	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth? PSK31 at is the difference between direct FSK and audio FSK? Direct FSK applies the data signal to the transmitter VFO, while AFSK transmits tones via phone
E2E09 E2E10 E2E11	Whi D Whi C Wha A	ch of the following HF digital modes can be used to transfer binary files? PACTOR ch of the following HF digital modes uses variable-length coding for bandwidth efficiency? PSK31 ch of these digital modes has the narrowest bandwidth? PSK31 at is the difference between direct FSK and audio FSK? Direct FSK applies the data signal to the transmitter VFO, while AFSK transmits tones via phone of do ALE stations establish contact? ALE constantly scans a list of frequencies, activating the radio when the designated call sign is

	E3: RADIO WAVE PROPAGATION
E3A:	Electromagnetic waves; Earth-Moon-Earth communications; meteor scatter; microwave tropospheric and scatter propagation; aurora propagation; ionospheric propagation changes over the day; circular polarization
E3A0	What is the approximate maximum separation measured along the surface of the Earth between two stations communicating by EME?
	D 12,000 miles, if the moon is visible by both stations
E3A0	What characterizes libration fading of an EME signal?
,	B A fluttery irregular fading
E3A0	When scheduling EME contacts, which of these conditions will generally result in the least path loss? A When the moon is at perigee
E3A0	What do Hepburn maps predict?
	D Probability of tropospheric propagation
E3A0	Tropospheric propagation of microwave signals often occurs in association with what phenomenon?
h	C Warm and cold fronts
E3A0	What might help to restore contact when DX signals become too weak to copy across an entire HF band a few hours after sunset?
	B Switch to a lower frequency HF band
E3A0	7 Atmospheric ducts capable of propagating microwave signals often form over what geographic feature?
ł	C Bodies of water
E3A0	When a meteor strikes the Earth's atmosphere, a cylindrical region of free electrons is formed at what layer of the ionosphere?
	A The E layer
E3A0	Which of the following frequency ranges is most suited for meteor scatter communications?
	C 28 MHz - 148 MHz
E3A1	Which type of atmospheric structure can create a path for microwave propagation?
LJAI	B Temperature inversion
F2.44	What is a trainal manage for two combonic managers of missons of m
E3A1	What is a typical range for tropospheric propagation of microwave signals? B 100 miles to 300 miles
E3A1	
	C The interaction in the E layer of charged particles from the Sun with the Earth's magnetic field
E3A1	Which of these emission modes is best for auroral propagation?
i	A CW

E3A14 What is meant by circularly polarized electromagnetic waves?

B Waves with a rotating electric field

	Wha	nt is transequatorial propagation?
		Propagation between two mid-latitude points at approximately the same distance north and south of the magnetic equator
E3B02	Wha	at is the approximate maximum range for signals using transequatorial propagation?
	С	5000 miles
E3B03	Wha	at is the best time of day for transequatorial propagation?
	С	Afternoon or early evening
E3B04	Wha	at is meant by the terms "extraordinary" and "ordinary" waves?
	В	Independent waves created in the ionosphere that are elliptically polarized
E3B05	Whi	ch amateur bands typically support long-path propagation?
		160 meters to 10 meters
	7	
E3B06		ch of the following amateur bands most frequently provides long-path propagation? 20 meters
E3B07	1	at happens to linearly polarized radio waves that split into ordinary and extraordinary waves in the
E3B07	iono C	They become elliptically polarized
	iond C Wha	osphere?
	iond C Wha	They become elliptically polarized It is the term for the long path opening that exists between two points on the Earth which are
E3B08	What sime	They become elliptically polarized It is the term for the long path opening that exists between two points on the Earth which are ultaneously near sunrise and sunset?
E3B08	What sime	They become elliptically polarized It is the term for the long path opening that exists between two points on the Earth which are ultaneously near sunrise and sunset? Grayline
E3B08 E3B09 E3B10	What sime	They become elliptically polarized It is the term for the long path opening that exists between two points on the Earth which are ultaneously near sunrise and sunset? Grayline What time of year is sporadic E propagation most likely to occur?
E3B08	What was a Why	They become elliptically polarized It is the term for the long path opening that exists between two points on the Earth which are ultaneously near sunrise and sunset? Grayline What time of year is sporadic E propagation most likely to occur? Around the solstices, especially the summer solstice
E3B08 E3B09 E3B10	What was a way of a control of the c	They become elliptically polarized It is the term for the long path opening that exists between two points on the Earth which are ultaneously near sunrise and sunset? Grayline They become elliptically polarized They become elliptically polari
E3B08 E3B09	What was a simple of the simpl	They become elliptically polarized at is the term for the long path opening that exists between two points on the Earth which are ultaneously near sunrise and sunset? Grayline what time of year is sporadic E propagation most likely to occur? Around the solstices, especially the summer solstice v is chordal hop propagation desirable? The signal experiences less loss compared to multi-hop using Earth as a reflector
E3B08 E3B09 E3B10 E3B11	Wha sime D At v A At v D	They become elliptically polarized at is the term for the long path opening that exists between two points on the Earth which are ultaneously near sunrise and sunset? Grayline That time of year is sporadic E propagation most likely to occur? Around the solstices, especially the summer solstice The signal experiences less loss compared to multi-hop using Earth as a reflector what time of day can sporadic E propagation occur?

E3C01	Wha	t does the radio communication term "ray tracing" describe?
	В	Modeling a radio wave's path through the ionosphere
	1	
E3C02	.i	t is indicated by a rising A or K index?
	A	Increasing disruption of the geomagnetic field
E3C03	Whi	ch of the following signal paths is most likely to experience high levels of absorption when the A index o
	:	dex is elevated?
	В	Polar
E3C04	Wh:	t does the value of Bz (B sub Z) represent?
E3C04	.)	Direction and strength of the interplanetary magnetic field
	C	Direction and strength of the interplanetary magnetic neith
E3C05	1	t orientation of Bz (B sub z) increases the likelihood that incoming particles from the sun will cause
		urbed conditions? Southward
	A	podulwalu
E3C06	By h	ow much does the VHF/UHF radio horizon distance exceed the geometric horizon?
	.;	By approximately 15 percent of the distance
	4	
E3C07	Whi	ch of the following descriptors indicates the greatest solar flare intensity?
	D	Class X
E3C08	Wha	t does the space weather term "G5" mean?
	.1	An extreme geomagnetic storm
	_	
E3C09	How	does the intensity of an X3 flare compare to that of an X2 flare?
	В	50 percent greater
E3C10	Wha	t does the 304A solar parameter measure?
LJCIU	.;	UV emissions at 304 angstroms, correlated to the solar flux index
E3C11	Wha	t does VOACAP software model?
	С	HF propagation
E2C12	Ha	does the maximum range of ground-wave propagation change when the signal frequency is increased
_3C12	.i	It decreases
	Č	
E3C13	.i	t type of polarization is best for ground-wave propagation?
	Α	Vertical
F264.4	\ A /I-	does the made math housen distance exceed the according beginning.
E3C14	.; -	does the radio-path horizon distance exceed the geometric horizon?
	D	Downward bending due to density variations in the atmosphere
E3C15	Wha	t might be indicated by a sudden rise in radio background noise across a large portion of the HF

E4: AMATEUR PRACTICES

F4A: Test equipment: analog and digital instruments; spectrum analyzers; antenna analyzers; oscilloscopes; RF measurements; computer-aided measurements E4A01 Which of the following limits the highest frequency signal that can be accurately displayed on a digital oscilloscope? A Sampling rate of the analog-to-digital converter Which of the following parameters does a spectrum analyzer display on the vertical and horizontal axes? E4A02 B RF amplitude and frequency E4A03 Which of the following test instruments is used to display spurious signals and/or intermodulation distortion products generated by an SSB transmitter? **B** A spectrum analyzer E4A04 How is the compensation of an oscilloscope probe typically adjusted? A square wave is displayed and the probe is adjusted until the horizontal portions of the displayed wave are as nearly flat as possible E4A05 What is the purpose of the prescaler function on a frequency counter? D It divides a higher frequency signal so a low-frequency counter can display the input frequency E4A06 What is the effect of aliasing on a digital oscilloscope caused by setting the time base too slow? A false, jittery low-frequency version of the signal is displayed E4A07 Which of the following is an advantage of using an antenna analyzer compared to an SWR bridge to measure antenna SWR? B Antenna analyzers do not need an external RF source E4A08 Which of the following measures SWR? An antenna analyzer Which of the following is good practice when using an oscilloscope probe? E4A09 A Keep the signal ground connection of the probe as short as possible E4A10 Which of the following displays multiple digital signal states simultaneously? D Logic analyzer E4A11 How should an antenna analyzer be connected when measuring antenna resonance and feed point impedance?

15 of 51 2/27/22, 16:13

D Connect the antenna feed line directly to the analyzer's connector

4B01	T				
	. i	ch of the following factors most affects the accuracy of a frequency counter?			
	В	Time base accuracy			
4B02	Wha	at is the significance of voltmeter sensitivity expressed in ohms per volt?			
	i	The full scale reading of the voltmeter multiplied by its ohms per volt rating will indicate the input impedance of the voltmeter			
4B03	Whi	ch S parameter is equivalent to forward gain?			
	С	S21			
	,,,,, .				
4B04		ch S parameter represents input port return loss or reflection coefficient (equivalent to VSWR)? S11			
	A	211			
4B05	Wha	at three test loads are used to calibrate an RF vector network analyzer?			
	В	Short circuit, open circuit, and 50 ohms			
	_				
4B06	Hov	much power is being absorbed by the load when a directional power meter connected between a			
_+000	transmitter and a terminating load reads 100 watts forward power and 25 watts reflected power?				
	tran				
	tran D				
	D	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts			
4B07	D Wha	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent?			
4B07	D Wha	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts			
	D Wha A	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent? The port or ports at which measurements are made			
4B07 4B08	Wha A Whi	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent? The port or ports at which measurements are made ch of the following can be used to measure the Q of a series-tuned circuit?			
	Wha A Whi	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent? The port or ports at which measurements are made			
4B08	What A Whit C	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent? The port or ports at which measurements are made ch of the following can be used to measure the Q of a series-tuned circuit?			
4B08	What A Whit C	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent? The port or ports at which measurements are made It is indicated if the current reading on an RF ammeter placed in series with the antenna feed line of a			
4B08 4B09	Wha A Whi C Wha tran	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent? The port or ports at which measurements are made It is indicated if the current reading on an RF ammeter placed in series with the antenna feed line of a smitter increases as the transmitter is tuned to resonance? There is more power going into the antenna			
4B08 4B09	What A What C What Trans	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent? The port or ports at which measurements are made It is indicated if the current reading on an RF ammeter placed in series with the antenna feed line of a smitter increases as the transmitter is tuned to resonance? There is more power going into the antenna It is following methods measures intermodulation distortion in an SSB transmitter?			
	What A What C What Trans	smitter and a terminating load reads 100 watts forward power and 25 watts reflected power? 75 watts It do the subscripts of S parameters represent? The port or ports at which measurements are made It is indicated if the current reading on an RF ammeter placed in series with the antenna feed line of a smitter increases as the transmitter is tuned to resonance? There is more power going into the antenna			

E4C01	,	cal mixing; selectivity; effects of SDR receiver non-linearity; use of attenuators at low frequencies It is an effect of excessive phase noise in a receiver's local oscillator?
4C01		·
	D	It can combine with strong signals on nearby frequencies to generate interference
4C02	Whi sign	ch of the following receiver circuits can be effective in eliminating interference from strong out-of-bandals?
	Α	A front-end filter or pre-selector
4C03	1	it is the term for the suppression in an FM receiver of one signal by another stronger signal on the sam uency?
	C	Capture effect
E4C04	Wha	t is the noise figure of a receiver?
	D	The ratio in dB of the noise generated by the receiver to the theoretical minimum noise
4C05	Wha	t does a receiver noise floor of -174 dBm represent?
_4003	В	The theoretical noise in a 1 Hz bandwidth at the input of a perfect receiver at room
		temperature
4C06		V receiver with the AGC off has an equivalent input noise power density of -174 dBm/Hz. What would I
		evel of an unmodulated carrier input to this receiver that would yield an audio output SNR of 0 dB in a Hz noise bandwidth?
	D	-148 dBm
E4C07	Wha	t does the MDS of a receiver represent?
	В	The minimum discernible signal
- 4 0 0 0		CDD was six and a constant of order to the constant of the con
4C08		DR receiver is overloaded when input signals exceed what level?
	D	The reference voltage of the analog-to-digital converter
4C09		ch of the following choices is a good reason for selecting a high frequency for the design of the IF in a erheterodyne HF or VHF communications receiver?
	С	Easier for front-end circuitry to eliminate image responses
- 4 0 4 0		the second and the second seco
E4C10		It is an advantage of having a variety of receiver IF bandwidths from which to select?
	С	Receive bandwidth can be set to match the modulation bandwidth, maximizing signal-to-noise ratio and minimizing interference
E4C11		can an attenuator be used to reduce receiver overload on the lower frequency HF bands with little or lact on signal-to-noise ratio?
	D	Atmospheric noise is generally greater than internally generated noise even after attenuation
E4C12	Whi	ch of the following has the largest effect on an SDR receiver's dynamic range?
_ 1012		Analog-to-digital converter sample width in bits
	D	Analog-to-digital Converter Sample width in Dits
E4C13	How	does a narrow-band roofing filter affect receiver performance?
	С	It improves dynamic range by attenuating strong signals near the receive frequency
E4C14	1	It transmit frequency might generate an image response signal in a receiver tuned to 14.300 MHz and uses a 455 kHz IF frequency?
	D	15.210 MHz
E4C15	Wha	t is reciprocal mixing?

What is meant by the blocking dynamic range of a receiver? A The difference in dB between the noise floor and the level of an incoming signal that will caus 1 dB of gain compression Which of the following describes problems caused by poor dynamic range in a receiver? A Spurious signals caused by cross-modulation and desensitization from strong adjacent signals how can intermodulation interference between two repeaters occur? B When the repeaters are in close proximity and the signals mix in the final amplifier of one or both transmitters E4D04 Which of the following may reduce or eliminate intermodulation interference in a repeater caused by another transmitter operating in close proximity? B A properly terminated circulator at the output of the repeater's transmitter E4D05 What transmitter frequencies would cause an intermodulation-product signal in a receiver tuned to 146.70 MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4D06 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation products that has the same output amplitude as either of the input signals E4D11 What odd-order products of two signals in the band of interest are also likely to be within the band required; E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received frequency?			ntercept; desensitization; preselector
E4D02 Which of the following describes problems caused by poor dynamic range in a receiver? A Spurious signals caused by cross-modulation and desensitization from strong adjacent signals. E4D03 How can intermodulation interference between two repeaters occur? B When the repeaters are in close proximity and the signals mix in the final amplifier of one or both transmitters. E4D04 Which of the following may reduce or eliminate intermodulation interference in a repeater caused by another transmiter operating in close proximity? B A properly terminated circulator at the output of the repeater's transmitter. E4D05 What transmitter frequencies would cause an intermodulation-product signal in a receiver tuned to 146.70 MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4D06 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band	E4D01	Wha	t is meant by the blocking dynamic range of a receiver?
A Spurious signals caused by cross-modulation and desensitization from strong adjacent signals. E4D03 How can intermodulation interference between two repeaters occur? B When the repeaters are in close proximity and the signals mix in the final amplifier of one or both transmitters. E4D04 Which of the following may reduce or eliminate intermodulation interference in a repeater caused by another transmitter operating in close proximity? B A properly terminated circulator at the output of the repeater's transmitter. E4D05 What transmitter frequencies would cause an intermodulation-product signal in a receiver tuned to 146.70 MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4D06 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation produt that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band		A	
How can intermodulation interference between two repeaters occur? B When the repeaters are in close proximity and the signals mix in the final amplifier of one or both transmitters E4D04 Which of the following may reduce or eliminate intermodulation interference in a repeater caused by another transmitter operating in close proximity? B A properly terminated circulator at the output of the repeater's transmitter E4D05 What transmitter frequencies would cause an intermodulation-product signal in a receiver tuned to 146.70 MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4D06 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band	E4D02		
B When the repeaters are in close proximity and the signals mix in the final amplifier of one or both transmitters Which of the following may reduce or eliminate intermodulation interference in a repeater caused by another transmitter operating in close proximity? B A properly terminated circulator at the output of the repeater's transmitter E4005 What transmitter frequencies would cause an intermodulation-product signal in a receiver tuned to 146.70 MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4006 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4007 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4008 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4009 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4010 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4011 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band		Α	Spurious signals caused by cross-modulation and desensitization from strong adjacent signals
both transmitters E4D04 Which of the following may reduce or eliminate intermodulation interference in a repeater caused by another transmitter operating in close proximity? B A properly terminated circulator at the output of the repeater's transmitter E4D05 What transmitter frequencies would cause an intermodulation-product signal in a receiver tuned to 146.70 MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4D06 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation produt that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band	E4D03	How	can intermodulation interference between two repeaters occur?
transmitter operating in close proximity? B A properly terminated circulator at the output of the repeater's transmitter E4D05 What transmitter frequencies would cause an intermodulation-product signal in a receiver tuned to 146.70 MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4D06 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band		В	·
B A properly terminated circulator at the output of the repeater's transmitter E4005 What transmitter frequencies would cause an intermodulation-product signal in a receiver tuned to 146.70 MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4006 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4007 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4008 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4009 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4010 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4011 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band	E4D04	1	
MHz when a nearby station transmits on 146.52 MHz? A 146.34 MHz and 146.61 MHz E4D06 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band			
E4D06 What is the term for spurious signals generated by the combination of two or more signals in a non-linear device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band	E4D05	MHz	when a nearby station transmits on 146.52 MHz?
device or circuit? D Intermodulation E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band		Α	146.34 MHz and 146.61 MHz
E4D07 Which of the following reduces the likelihood of receiver desensitization? A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received	E4D06	1	· · · · · · · · · · · · · · · · · · ·
A Decrease the RF bandwidth of the receiver E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received		D	Intermodulation
E4D08 What causes intermodulation in an electronic circuit? C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received	E4D07	Whi	ch of the following reduces the likelihood of receiver desensitization?
C Nonlinear circuits or devices E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received		A	Decrease the RF bandwidth of the receiver
E4D09 What is the purpose of the preselector in a communications receiver? C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received	E4D08	Wha	t causes intermodulation in an electronic circuit?
C To increase rejection of signals outside the desired band E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received		C	Nonlinear circuits or devices
E4D10 What does a third-order intercept level of 40 dBm mean with respect to receiver performance? C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received	E4D09	Wha	t is the purpose of the preselector in a communications receiver?
C A pair of 40 dBm input signals will theoretically generate a third-order intermodulation product that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received		С	To increase rejection of signals outside the desired band
that has the same output amplitude as either of the input signals E4D11 Why are odd-order intermodulation products, created within a receiver, of particular interest compared to other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received	E4D10	Wha	t does a third-order intercept level of 40 dBm mean with respect to receiver performance?
other products? A Odd-order products of two signals in the band of interest are also likely to be within the band E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received		С	
E4D12 What is the term for the reduction in receiver sensitivity caused by a strong signal near the received	E4D11		
		A	Odd-order products of two signals in the band of interest are also likely to be within the band
	E4D12	:	, , , , , , , , , , , , , , , , , , , ,

		suppression and interference: system noise; electrical appliance noise; line noise; locating noise sources; DSP noise on; noise blankers; grounding for signals; common mode currents
E4E01		It problem can occur when using an automatic notch filter (ANF) to remove interfering carriers while viving CW signals?
	A	Removal of the CW signal as well as the interfering carrier
E4E02	Whi	ch of the following types of noise can often be reduced with a digital signal processing noise filter?
	D	All these choices are correct
E4E03	Whi	ch of the following signals might a receiver noise blanker be able to remove from desired signals?
	В	Signals that appear across a wide bandwidth
E4E04	How	can conducted and radiated noise caused by an automobile alternator be suppressed?
	D	By connecting the radio's power leads directly to the battery and by installing coaxial capacitors in line with the alternator leads
E4E05	How	can radio frequency interference from an AC motor be suppressed?
	В	By installing a brute-force AC-line filter in series with the motor leads
E4E06	Wha	it is one type of electrical interference that might be caused by a nearby personal computer?
	С	The appearance of unstable modulated or unmodulated signals at specific frequencies
E4E07	Whi	ch of the following can cause shielded cables to radiate or receive interference?
	В	Common-mode currents on the shield and conductors
E4E08	Wha	at current flows equally on all conductors of an unshielded multi-conductor cable?
	В	Common-mode current
E4E09	Wha	nt undesirable effect can occur when using an IF noise blanker?
	С	Nearby signals may appear to be excessively wide even if they meet emission standards
E4E10	Wha	it might be the cause of a loud roaring or buzzing AC line interference that comes and goes at intervals
	D	All these choices are correct
E4E11	Wha ban	at could cause local AM broadcast band signals to combine to generate spurious signals in the MF or HF
	В	Nearby corroded metal joints are mixing and re-radiating the broadcast signals

E5: ELECTRICAL PRINCIPLES

E5A: Resonance and Q: characteristics of resonant circuits: series and parallel resonance; definitions and effects of Q; half-power bandwidth; phase relationships in reactive circuits E5A01 What can cause the voltage across reactances in a series RLC circuit to be higher than the voltage applied to the entire circuit? Resonance What is resonance in an LC or RLC circuit? E5A02 C The frequency at which the capacitive reactance equals the inductive reactance E5A03 What is the magnitude of the impedance of a series RLC circuit at resonance? D Approximately equal to circuit resistance F5A04 What is the magnitude of the impedance of a parallel RLC circuit at resonance? A Approximately equal to circuit resistance E5A05 What is the result of increasing the Q of an impedance-matching circuit? A Matching bandwidth is decreased E5A06 What is the magnitude of the circulating current within the components of a parallel LC circuit at resonance? B It is at a maximum What is the magnitude of the current at the input of a parallel RLC circuit at resonance? E5A07 A Minimum What is the phase relationship between the current through and the voltage across a series resonant circuit E5A08 The voltage and current are in phase E5A09 How is the Q of an RLC parallel resonant circuit calculated? C Resistance divided by the reactance of either the inductance or capacitance E5A10 How is the Q of an RLC series resonant circuit calculated? A Reactance of either the inductance or capacitance divided by the resistance E5A11 What is the half-power bandwidth of a resonant circuit that has a resonant frequency of 7.1 MHz and a Q of 150? C 47.3 kHz E5A12 What is the half-power bandwidth of a resonant circuit that has a resonant frequency of 3.7 MHz and a Q of 118? C 31.4 kHz E5A13 What is an effect of increasing Q in a series resonant circuit? C Internal voltages increase What is the resonant frequency of an RLC circuit if R is 22 ohms, L is 50 microhenries and C is 40 picofarads? E5A14 C 3.56 MHz E5A15 Which of the following increases Q for inductors and capacitors? A Lower losses E5A16 What is the resonant frequency of an RLC circuit if R is 33 ohms, L is 50 microhenries and C is 10 picofarads? D 7.12 MHz

		ance and susceptance
E5B01	1	t is the term for the time required for the capacitor in an RC circuit to be charged to 63.2% of the applie
	volt	age or to discharge to 36.8% of its initial voltage?
	В	One time constant
E5B02	Wha	t letter is commonly used to represent susceptance?
	D	В
F5B03	Ном	is impedance in polar form converted to an equivalent admittance?
LJD03	.j	Take the reciprocal of the magnitude and change the sign of the angle
	ь	Take the reciprocal of the magnitude and change the sign of the angle
E5B04	Wha	t is the time constant of a circuit having two 220 microfarad capacitors and two 1 megohm resistors, all
23201	.1	arallel?
	D	220 seconds
FEROE	\4/b-	
E5B05	.]	t happens to the magnitude of a pure reactance when it is converted to a susceptance?
	D	It becomes the reciprocal
E5B06	Wha	t is susceptance?
	C	The imaginary part of admittance
E5B07	1	t is the phase angle between the voltage across and the current through a series RLC circuit if XC is 500 s, R is 1 kilohm, and XL is 250 ohms?
		14.0 degrees with the voltage lagging the current
	•••	
E5B08	1	t is the phase angle between the voltage across and the current through a series RLC circuit if XC is 100
		s, R is 100 ohms, and XL is 75 ohms?
	Α	14 degrees with the voltage lagging the current
E5B09	Wha	t is the relationship between the AC current through a capacitor and the voltage across a capacitor?
	.;	Current leads voltage by 90 degrees
	_	
E5B10	Wha	t is the relationship between the AC current through an inductor and the voltage across an inductor?
	Α	Voltage leads current by 90 degrees
E5B11		t is the phase angle between the voltage across and the current through a series RLC circuit if XC is 25
		s, R is 100 ohms, and XL is 50 ohms?
	В	14 degrees with the voltage leading the current
E5B12	\A/!	t is admittance?

E5C01	Whi	ch of the following represents capacitive reactance in rectangular notation?
LJCOI	i	-jx
E5C02	How	are impedances described in polar coordinates?
	C	By phase angle and magnitude
E5C03	Whi	ch of the following represents an inductive reactance in polar coordinates?
	С	A positive phase angle
E5C04	Wha	t coordinate system is often used to display the resistive, inductive, and/or capacitive reactance
LJC04	1	ponents of impedance?
	D	Rectangular coordinates
	1	*
E5C05	:	t is the name of the diagram used to show the phase relationship between impedances at a given uency?
	•	Phasor diagram
	·	l ilusor diagram
E5C06	Wha	t does the impedance 50-j25 represent?
	В	50 ohms resistance in series with 25 ohms capacitive reactance
E5C07	Whe	re is the impedance of a pure resistance plotted on rectangular coordinates?
	D	On the horizontal axis
	7	
E5C08	i	it coordinate system is often used to display the phase angle of a circuit containing resistance, inductive or capacitive reactance?
		Polar coordinates
	D	Polar Coordinates
E5C09	Whe	n using rectangular coordinates to graph the impedance of a circuit, what do the axes represent?
	Α	The X axis represents the resistive component and the Y axis represents the reactive
		component
FFC12	\A/I- ·	ab unit on Figure EF 4 host represents the immediance of a contractive size of \$400 days of \$400 days.
E5C10	;	ch point on Figure E5-1 best represents the impedance of a series circuit consisting of a 400-ohm resisto a 38-picofarad capacitor at 14 MHz? (view image)
		Point 4
	_	
E5C11	Whi	ch point in Figure E5-1 best represents the impedance of a series circuit consisting of a 300-ohm resistor
	and	an 18-microhenry inductor at 3.505 MHz? (view image)
	В	Point 3
E5C12	Whi	ch point on Figure E5-1 best represents the impedance of a series circuit consisting of a 300-ohm resisto
LJCIZ	i	
	and	a 19-picofarad capacitor at 21.200 MHz? (view image)

	Jiiaac	tors at UHF and microwave frequencies; microstrip
E5D01	Wha	t is the result of skin effect?
	Α	As frequency increases, RF current flows in a thinner layer of the conductor, closer to the surface
E5D02	Why	is it important to keep lead lengths short for components used in circuits for VHF and above?
	В	To avoid unwanted inductive reactance
E5D03	Wha	t is microstrip?
	D	Precision printed circuit conductors above a ground plane that provide constant impedance interconnects at microwave frequencies
E5D04	Why	are short connections used at microwave frequencies?
	В	To reduce phase shift along the connection
E5D05	Wha curr	t is the power factor of an RL circuit having a 30-degree phase angle between the voltage and the ent?
	С	0.866
E5D06	In w	hat direction is the magnetic field oriented about a conductor in relation to the direction of electron flow
	D	In a circle around the conductor
E5D07	.i	many watts are consumed in a circuit having a power factor of 0.71 if the apparent power is 500VA?
	•	
E5D08	j	many watts are consumed in a circuit having a power factor of 0.6 if the input is 200VAC at 5 amperes? 600 watts
EED00	\A/b =	t happens to reactive power in an AC circuit that has both ideal inductors and ideal capacitors?
E5D09	į.	It is repeatedly exchanged between the associated magnetic and electric fields, but is not dissipated
E5D10		can the true power be determined in an AC circuit where the voltage and current are out of phase?
	Α	By multiplying the apparent power by the power factor
E5D11	Wha curr	t is the power factor of an RL circuit having a 60-degree phase angle between the voltage and the ent?
	С	0.5
E5D12	.;	many watts are consumed in a circuit having a power factor of 0.2 if the input is 100 VAC at 4 amperes
	В	80 watts
E5D13	:	many watts are consumed in a circuit consisting of a 100-ohm resistor in series with a 100-ohm ctive reactance drawing 1 ampere?
	В	100 watts
E5D14	1	t is reactive power? Wattless, nonproductive power
E5D15	Wha	t is the power factor of an RL circuit having a 45-degree phase angle between the voltage and the
LJDIJ		

	E6: CIRCUIT COMPONENTS
	emiconductor materials and devices: semiconductor materials; germanium, silicon, P-type, N-type; transistor types: NPN, NP, junction, field-effect transistors: enhancement mode; depletion mode; MOS; CMOS; N-channel; P-channel
E6A01	In what application is gallium arsenide used as a semiconductor material?
	C In microwave circuits
E6A02	Which of the following semiconductor materials contains excess free electrons?
LONGE	A N-type
E6A03	Why does a PN-junction diode not conduct current when reverse biased?
	C Holes in P-type material and electrons in the N-type material are separated by the applied voltage, widening the depletion region
E6A04	What is the name given to an impurity atom that adds holes to a semiconductor crystal structure?
	C Acceptor impurity
E6A05	How does DC input impedance at the gate of a field-effect transistor compare with the DC input impedance of a bipolar transistor?
	C An FET has higher input impedance
-c	
E6A06	What is the beta of a bipolar junction transistor? B The change in collector current with respect to base current
	The change in concecor current with respect to base current
E6A07	Which of the following indicates that a silicon NPN junction transistor is biased on?
	D Base-to-emitter voltage of approximately 0.6 to 0.7 volts
E6A08	What term indicates the frequency at which the grounded-base current gain of a transistor has decreased to
EDAU8	0.7 of the gain obtainable at 1 kHz?
	D Alpha cutoff frequency
I	1
E6A09	What is a depletion-mode FET? A An FET that exhibits a current flow between source and drain when no gate voltage is applied
	A MITTER that exhibits a carrent new between source and aram when no gate voltage is applied
E6A10	In Figure E6-1, what is the schematic symbol for an N-channel dual-gate MOSFET?
h	B 4
E6A11	In Figure E6-1, what is the schematic symbol for a P-channel junction FET? A 1
	^
E6A12	Why do many MOSFET devices have internally connected Zener diodes on the gates?

D To reduce the chance of static damage to the gate

B: D	iodes
E6B01	What is the most useful characteristic of a Zener diode?
	B A constant voltage drop under conditions of varying current
E6B02	What is an important characteristic of a Schottky diode as compared to an ordinary silicon diode when used as a power supply rectifier?
	D Less forward voltage drop
E6B03	What type of bias is required for an LED to emit light?
	B Forward bias
E6B04	What type of semiconductor device is designed for use as a voltage-controlled capacitor?
	A Varactor diode
E6B05	What characteristic of a PIN diode makes it useful as an RF switch?
	D Low junction capacitance
E6B06	Which of the following is a common use of a Schottky diode?
	D As a VHF/UHF mixer or detector
E6B07	What is the failure mechanism when a junction diode fails due to excessive current?
	B Excessive junction temperature
E6B08	Which of the following is a Schottky barrier diode?
	A Metal-semiconductor junction
E6B09	What is a common use for point-contact diodes?
	C As an RF detector
E6B10	In Figure E6-2, what is the schematic symbol for a light-emitting diode?
	B 5
E6B11	What is used to control the attenuation of RF signals by a PIN diode?
	A Forward DC bias current

E6C01	i	It is the function of hysteresis in a comparator?
	Α	To prevent input noise from causing unstable output signals
E6C02	Wha	t happens when the level of a comparator's input signal crosses the threshold?
	В	The comparator changes its output state
E6C03		it is tri-state logic?
	Α	Logic devices with 0, 1, and high-impedance output states
E6C04	Whi	ch of the following is an advantage of BiCMOS logic?
	С	It has the high input impedance of CMOS and the low output impedance of bipolar transistors
E6C05	Wha	nt is an advantage of CMOS logic devices over TTL devices?
	D	Lower power consumption
E6C06	Why	do CMOS digital integrated circuits have high immunity to noise on the input signal or power supply?
	С	The input switching threshold is about one-half the power supply voltage
E6C07	Wha	nt best describes a pull-up or pull-down resistor?
	В	A resistor connected to the positive or negative supply line used to establish a voltage when a input or output is an open circuit
E6C08	In F	igure E6-3, what is the schematic symbol for a NAND gate?
	В	2
E6C09	Wha	nt is a Programmable Logic Device (PLD)?
	В	A programmable collection of logic gates and circuits in a single integrated circuit
E6C10	In F	igure E6-3, what is the schematic symbol for a NOR gate?
	D	4
E6C11	In F	igure E6-3, what is the schematic symbol for the NOT operation (inverter)?
	C	5

E6D01	Why	should core saturation of an impedance matching transformer be avoided?
	Α	Harmonics and distortion could result
E6D02	:	at is the equivalent circuit of a quartz crystal?
	Α	Motional capacitance, motional inductance, and loss resistance in series, all in parallel with a shunt capacitor representing electrode and stray capacitance
		Shunt Capacitor representing electrode and stray Capacitance
F6D03	Whi	ch of the following is an aspect of the piezoelectric effect?
		Mechanical deformation of material by the application of a voltage
E6D04	Whi	ch materials are commonly used as a core in an inductor?
	В	Ferrite and brass
	·	
E6D05	Wha	et is one reason for using ferrite cores rather than powdered iron in an inductor?
	С	Ferrite toroids generally require fewer turns to produce a given inductance value
TCD0C	\A/b-	at core material property determines the inductance of an inductor?
E6D06	;	
	D	Permeability
E6D07	Wha	at is current in the primary winding of a transformer called if no load is attached to the secondary?
	i	Magnetizing current
E6D08	Wha	at is one reason for using powdered-iron cores rather than ferrite cores in an inductor?
	В	Powdered-iron cores generally maintain their characteristics at higher currents
	-	
E6D09		it devices are commonly used as VHF and UHF parasitic suppressors at the input and output terminals of sistor HF amplifier?
		Ferrite beads
	Č	TOTTIC DOUG
E6D10	Wha	at is a primary advantage of using a toroidal core instead of a solenoidal core in an inductor?
	Α	Toroidal cores confine most of the magnetic field within the core material
E6D11	Whi	ch type of core material decreases inductance when inserted into a coil?
	В	Brass
L61117	!	at is inductor saturation?
LUDIZ		The ability of the inductor's core to store magnetic energy has been exceeded
LODIZ	C	including of the mudetor 3 core to store magnetic energy has been exceeded
E6D13	٦ _	at is the primary cause of inductor self-resonance?

f		ICs: MMICs, IC packaging characteristics
E6E01	! -	r is gallium arsenide (GaAs) useful for semiconductor devices operating at UHF and higher frequencies?
	В	Higher electron mobility
E6E02	Whi	ch of the following device packages is a through-hole type?
		DIP
E6E03	Whi	ch of the following materials is likely to provide the highest frequency of operation when used in MMICs?
	D	Gallium nitride
F6F04	va/b:	sh is the west common input and output impedance of singuite that use MMTCs2
E6E04)	ch is the most common input and output impedance of circuits that use MMICs? 50 ohms
E6E05	Whi	ch of the following noise figure values is typical of a low-noise UHF preamplifier?
<u> </u>	Α	2 dB
·	••••	
E6E06	Wha	t characteristics of the MMIC make it a popular choice for VHF through microwave circuits?
	D	Controlled gain, low noise figure, and constant input and output impedance over the specified frequency range
E6E07	Wha	at type of transmission line is used for connections to MMICs?
	D	Microstrip
E6E08	Ном	is power supplied to the most common type of MMIC?
EOEUO		Through a resistor and/or RF choke connected to the amplifier output lead
E6E09	Whi	ch of the following component package types would be most suitable for use at frequencies above the HF
i	rang	ge?
	D	Surface mount
E6E10	Wha	at advantage does surface-mount technology offer at RF compared to using through-hole components?
	D	All these choices are correct
	···]	
E6E11	Wha	It is a characteristic of DIP packaging used for integrated circuits?
	D	A total of two rows of connecting pins placed on opposite sides of the package (Dual In-line Package)
E6E12	Why	are DIP through-hole package ICs not typically used at UHF and higher frequencies?
	С	Excessive lead length

E6F01		
LOI OT	Wha	t absorbs the energy from light falling on a photovoltaic cell?
	С	Electrons
	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	
E6F02		t happens to the conductivity of a photoconductive material when light shines on it? It increases
		at moreuses
E6F03	Wha	t is the most common configuration of an optoisolator or optocoupler?
	D	An LED and a phototransistor
E6F04	Wha	t is the photovoltaic effect?
	В	The conversion of light to electrical energy
E6F05	Whi	ch describes an optical shaft encoder?
LOI 03		A device that detects rotation of a control by interrupting a light source with a patterned when
E6F06		ch of these materials is most commonly used to create photoconductive devices?
F6F07		A crystalline semiconductor t is a solid-state relay?
E6F07	Wha	t is a solid-state relay?
E6F07	Wha	
E6F07	Wha B	t is a solid-state relay?
	Wha B Why	t is a solid-state relay? A device that uses semiconductors to implement the functions of an electromechanical relay
	Wha B Why C	t is a solid-state relay? A device that uses semiconductors to implement the functions of an electromechanical relay are optoisolators often used in conjunction with solid-state circuits when switching 120 VAC? Optoisolators provide a very high degree of electrical isolation between a control circuit and
E6F08	Wha B Why C	t is a solid-state relay? A device that uses semiconductors to implement the functions of an electromechanical relay are optoisolators often used in conjunction with solid-state circuits when switching 120 VAC? Optoisolators provide a very high degree of electrical isolation between a control circuit and the circuit being switched
E6F08	Wha B Why C	t is a solid-state relay? A device that uses semiconductors to implement the functions of an electromechanical relay are optoisolators often used in conjunction with solid-state circuits when switching 120 VAC? Optoisolators provide a very high degree of electrical isolation between a control circuit and the circuit being switched t is the efficiency of a photovoltaic cell?
E6F08	Wha B Why C Wha D	t is a solid-state relay? A device that uses semiconductors to implement the functions of an electromechanical relay are optoisolators often used in conjunction with solid-state circuits when switching 120 VAC? Optoisolators provide a very high degree of electrical isolation between a control circuit and the circuit being switched t is the efficiency of a photovoltaic cell? The relative fraction of light that is converted to current
E6F09	Wha B Why C Wha D	t is a solid-state relay? A device that uses semiconductors to implement the functions of an electromechanical relay are optoisolators often used in conjunction with solid-state circuits when switching 120 VAC? Optoisolators provide a very high degree of electrical isolation between a control circuit and the circuit being switched t is the efficiency of a photovoltaic cell? The relative fraction of light that is converted to current t is the most common type of photovoltaic cell used for electrical power generation?

	E7: PRACTICAL CIRCUITS	
	gital circuits: digital circuit principles and logic circuits; classes of logic elements; positive and negative logic; frequency viders; truth tables	
E7A01	Which circuit is bistable?	
	C A flip-flop]
E7A02	What is the function of a decade counter?	
	A It produces one output pulse for every 10 input pulses	
E7A03	Which of the following can divide the frequency of a pulse train by 2?	
	B A flip-flop	
E7A04	How many flip-flops are required to divide a signal frequency by 4?	
	B 2	_
E7A05	Which of the following is a circuit that continuously alternates between two states without an external clock?	,
	D Astable multivibrator]
E7A06	What is a characteristic of a monostable multivibrator?	"]
	A It switches momentarily to the opposite binary state and then returns to its original state after a set time	
E7A07	What logical operation does a NAND gate perform?	
	D It produces logic 0 at its output only when all inputs are logic 1	
E7A08	What logical operation does an OR gate perform?	
	A It produces logic 1 at its output if any or all inputs are logic 1	_
E7A09	What logical operation is performed by an exclusive NOR gate?	
	C It produces logic 0 at its output if only one input is logic 1	
E7A10	What is a truth table?	
	C A list of inputs and corresponding outputs for a digital device	_
E7A11	What type of logic defines "1" as a high voltage?	
	D Positive Logic	

		ers: Class of operation; vacuum tube and solid-state circuits; distortion and intermodulation; spurious and parasitic ssion; microwave amplifiers; switching-type amplifiers
E7D01	Ecz	what portion of the cignal cycle door each active element in a nucle mult Class AD amplifier conducts
E/B01	.i	what portion of the signal cycle does each active element in a push-pull Class AB amplifier conduct? More than 180 degrees but less than 360 degrees
F7B02	Wha	at is a Class D amplifier?
L/D02	.j	A type of amplifier that uses switching technology to achieve high efficiency
E7B03	Whi	ch of the following components form the output of a class D amplifier circuit?
	Α	A low-pass filter to remove switching signal components
	7 .	
E7B04	.i	ere on the load line of a Class A common emitter amplifier would bias normally be set? Approximately halfway between saturation and cutoff
	^	Approximately nanway between saturation and cuton
E7B05	Wha	at can be done to prevent unwanted oscillations in an RF power amplifier?
	C	Install parasitic suppressors and/or neutralize the stage
	••	
E7B06	.;	ch of the following amplifier types reduces even-order harmonics?
	В	Push-pull
E7B07	Whi	ch of the following is a likely result when a Class C amplifier is used to amplify a single-sideband phone
L/DU/	sign	
	D	Signal distortion and excessive bandwidth
	7	
E7B08	.i	can an RF power amplifier be neutralized?
	С	By feeding a 180-degree out-of-phase portion of the output back to the input
E7B09	Whi	ch of the following describes how the loading and tuning capacitors are to be adjusted when tuning a
	vacı	uum tube RF power amplifier that employs a Pi-network output circuit?
	D	The tuning capacitor is adjusted for minimum plate current, and the loading capacitor is
		adjusted for maximum permissible plate current
E7B10	In F	igure E7-1, what is the purpose of R1 and R2?
	В	Voltage divider bias
E7B11	In F	igure E7-1, what is the purpose of R3?
	D	Self bias
E7B12	Wha	at type of amplifier circuit is shown in Figure E7-1?
L/D1Z	.i	Common emitter
	C	Common emitter
E7B13	Whi	ch of the following describes an emitter follower (or common collector) amplifier?
	D	An amplifier with a low impedance output that follows the base input voltage
E7B14	.;	rare switching amplifiers more efficient than linear amplifiers?
	В	The power transistor is at saturation or cutoff most of the time
E7B15	Wha	at is one way to prevent thermal runaway in a bipolar transistor amplifier?
	.i	Use a resistor in series with the emitter
E7B16	.1	at is the effect of intermodulation products in a linear power amplifier?
	Α	Transmission of spurious signals

	: wh	rare odd-order rather than even-order intermodulation distortion products of concern in linear power
E7B17		lifiers?

E7B18 What is a characteristic of a grounded-grid amplifier?

C Low input impedance

E7C01	Ном	are the capacitors and inductors of a low-pass filter Pi-network arranged between the network's input
E/C01	1	output?
	D	A capacitor is connected between the input and ground, another capacitor is connected between the output and ground, and an inductor is connected between input and output
E7C02	Whi	ch of the following is a property of a T-network with series capacitors and a parallel shunt inductor?
	С	It is a high-pass filter
E7C03		t advantage does a series-L Pi-L-network have over a series-L Pi-network for impedance matching veen the final amplifier of a vacuum-tube transmitter and an antenna?
	Α	Greater harmonic suppression
E7C04	How	does an impedance-matching circuit transform a complex impedance to a resistive impedance?
	C	It cancels the reactive part of the impedance and changes the resistive part to a desired value
E7C05	Whi	ch filter type is described as having ripple in the passband and a sharp cutoff?
L/C03	.1	A Chebyshev filter
	7	· · · · · · · · · · · · · · · · · · ·
E7C06	.i	t are the distinguishing features of an elliptical filter?
	С	Extremely sharp cutoff with one or more notches in the stop band
E7C07	Whie outp	ch describes a Pi-L-network used for matching a vacuum tube final amplifier to a 50-ohm unbalanced out?
	В	A Pi-network with an additional series inductor on the output
E7C08		ch of the following factors has the greatest effect on the bandwidth and response shape of a crystal er filter?
	A	The relative frequencies of the individual crystals
E7C09	Wha	t is a crystal lattice filter?
	.i	A filter with narrow bandwidth and steep skirts made using quartz crystals ~~
E7C10	.)	ch of the following filters would be the best choice for use in a 2 meter band repeater duplexer? A cavity filter
		A Cavity filter
E7C11	Whi	ch of the following describes a receiving filter's ability to reject signals occupying an adjacent channel?
	С	Shape factor
E7C12	Wha	t is one advantage of a Pi-matching network over an L-matching network consisting of a single inducto
		a single capacitor?

	Hov	v does a linear electronic voltage regulator work?
	D	The conduction of a control element is varied to maintain a constant output voltage
F7D02	Wha	at is a characteristic of a switching electronic voltage regulator?
		The controlled device's duty cycle is changed to produce a constant average output voltage
		, , , , , , , , , , , , , , , , , , , ,
E7D03		at device is typically used as a stable voltage reference in a linear voltage regulator?
	Α	A Zener diode
E7D04	1	ch of the following types of linear voltage regulator usually make the most efficient use of the primary er source?
	В	A series regulator
E7D05		ch of the following types of linear voltage regulator places a constant load on the unregulated voltage rce?
	D	A shunt regulator
E7D06	Wha	at is the purpose of Q1 in the circuit shown in Figure E7-2?
		It controls the current supplied to the load
	,	
E7D07		at is the purpose of C2 in the circuit shown in Figure E7-2?
	Α	It bypasses rectifier output ripple around D1
	\ A/l	At the set singuithing the complete Figure F7 22
E7D08	!	at type of circuit is shown in Figure E7-2?
	С	Linear voltage regulator
	,	
E7D09	Wha	at is the main reason to use a charge controller with a solar power system?
E7D09	Wha C	et is the main reason to use a charge controller with a solar power system? Prevention of battery damage due to overcharge
E7D09	C	Prevention of battery damage due to overcharge
E7D09 E7D10	C	Prevention of battery damage due to overcharge
	C	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both lesensive and lighter in weight than a conventional power supply?
E7D10	Wha exp	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both lesensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for
E7D10	Wha exp	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both lessensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output
E7D10 E7D11	C Wha exp C Wha	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both less ensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output at is the function of the pass transistor in a linear voltage regulator circuit? Maintains nearly constant output voltage over a wide range of load current
E7D10 E7D11	C Wha exp C Wha	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both lesensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output at is the function of the pass transistor in a linear voltage regulator circuit?
E7D10 E7D11 E7D12	Whatexports C Whate C C	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both less ensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output at is the function of the pass transistor in a linear voltage regulator circuit? Maintains nearly constant output voltage over a wide range of load current at is the dropout voltage of an analog voltage regulator? Minimum input-to-output voltage required to maintain regulation
E7D10 E7D11 E7D12	Whatexports C Whate C C	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both lesensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output at is the function of the pass transistor in a linear voltage regulator circuit? Maintains nearly constant output voltage over a wide range of load current at is the dropout voltage of an analog voltage regulator? Minimum input-to-output voltage required to maintain regulation at is the equation for calculating power dissipated by a series linear voltage regulator?
E7D10 E7D11 E7D12	Whatexports C Whate C C	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both less ensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output at is the function of the pass transistor in a linear voltage regulator circuit? Maintains nearly constant output voltage over a wide range of load current at is the dropout voltage of an analog voltage regulator? Minimum input-to-output voltage required to maintain regulation
E7D10 E7D11 E7D12	Whate C What C C	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both lessensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output at is the function of the pass transistor in a linear voltage regulator circuit? Maintains nearly constant output voltage over a wide range of load current at is the dropout voltage of an analog voltage regulator? Minimum input-to-output voltage required to maintain regulation at is the equation for calculating power dissipated by a series linear voltage regulator? Voltage difference from input to output multiplied by output current at is the purpose of connecting equal-value resistors across power supply filter capacitors connected in
E7D10 E7D11 E7D12 E7D13	Whate C What C What C	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both lessensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output at is the function of the pass transistor in a linear voltage regulator circuit? Maintains nearly constant output voltage over a wide range of load current at is the dropout voltage of an analog voltage regulator? Minimum input-to-output voltage required to maintain regulation at is the equation for calculating power dissipated by a series linear voltage regulator? Voltage difference from input to output multiplied by output current at is the purpose of connecting equal-value resistors across power supply filter capacitors connected in
E7D10 E7D11 E7D12 E7D13	Whate C Whate Seri D	Prevention of battery damage due to overcharge at is the primary reason that a high-frequency switching type high-voltage power supply can be both lessensive and lighter in weight than a conventional power supply? The high frequency inverter design uses much smaller transformers and filter components for an equivalent power output at is the function of the pass transistor in a linear voltage regulator circuit? Maintains nearly constant output voltage over a wide range of load current at is the dropout voltage of an analog voltage regulator? Minimum input-to-output voltage required to maintain regulation at is the equation for calculating power dissipated by a series linear voltage regulator? Voltage difference from input to output multiplied by output current at is the purpose of connecting equal-value resistors across power supply filter capacitors connected in es?

E7E: M	odula	tion and demodulation: reactance, phase and balanced modulators; detectors; mixer stages
E7E01	Whi	ch of the following can be used to generate FM phone emissions?
<u></u>	В	A reactance modulator on the oscillator
	i	
E7E02	Wha	It is the function of a reactance modulator?
	D	To produce PM or FM signals by using an electrically variable inductance or capacitance
E7E03	Wha	t is a frequency discriminator stage in a FM receiver?
	D	A circuit for detecting FM signals
E7E04	Wha	t is one way a single-sideband phone signal can be generated?
L		By using a balanced modulator followed by a filter
E7E05	Wha	t circuit is added to an FM transmitter to boost the higher audio frequencies?
	D	A pre-emphasis network
·	ı	
E7E06	-	is de-emphasis commonly used in FM communications receivers?
	A	For compatibility with transmitters using phase modulation
E7E07	Wha	t is meant by the term "baseband" in radio communications?
E/EU/	į	The frequency range occupied by a message signal prior to modulation
	В	The frequency range occupied by a message signal prior to modulation
E7E08	Wha	t are the principal frequencies that appear at the output of a mixer circuit?
	С	The two input frequencies along with their sum and difference frequencies
	.	
E7E09	į	t occurs when an excessive amount of signal energy reaches a mixer circuit?
	A	Spurious mixer products are generated
E7E10	Ном	does a diode envelope detector function?
L/L10	:	By rectification and filtering of RF signals
E7E11	Whi	ch type of detector circuit is used for demodulating SSB signals?
	С	Product detector

E7F01	Wha	t is meant by direct digital conversion as applied to software defined radios?
	C	Incoming RF is digitized by an analog-to-digital converter without being mixed with a local oscillator signal
E7F02	Wha sign	t kind of digital signal processing audio filter is used to remove unwanted noise from a received SSB
	A	An adaptive filter
E7F03		t type of digital signal processing filter is used to generate an SSB signal?
	С	A Hilbert-transform filter
E7F04	Wha	t is a common method of generating an SSB signal using digital signal processing?
	D	Signals are combined in quadrature phase relationship
E7F05	1	frequently must an analog signal be sampled by an analog-to-digital converter so that the signal can be rately reproduced?
		At least twice the rate of the highest frequency component of the signal
E7F06		t is the minimum number of bits required for an analog-to-digital converter to sample a signal with a e of 1 volt at a resolution of 1 millivolt?
	D	10 bits
E7F07	Wha	t function is performed by a Fast Fourier Transform?
	С	Converting digital signals from the time domain to the frequency domain
E7F08	Wha	t is the function of decimation?
	В	Reducing the effective sample rate by removing samples
E7F09	;	is an anti-aliasing digital filter required in a digital decimator? It removes high-frequency signal components that would otherwise be reproduced as lower frequency components
E7F10	:	t aspect of receiver analog-to-digital conversion determines the maximum receive bandwidth of a Directal Conversion SDR?
	A	Sample rate
E7F11	:	t sets the minimum detectable signal level for a direct-sampling SDR receiver in the absence of ospheric or thermal noise?
	В	Reference voltage level and sample width in bits
E7F12		ch of the following is an advantage of a Finite Impulse Response (FIR) filter vs an Infinite Impulse ponse (IIR) digital filter?
		FIR filters can delay all frequency components of the signal by the same amount
	Wha	t is the function of taps in a digital signal processing filter?
E7F13		
E7F13	D	Provide incremental signal delays for filter algorithms

E7G01	Wha	t is the typical output impedance of an op-amp?
	Α	Very low
E7G02	Wha	t is ringing in a filter?
	D	Undesired oscillations added to the desired signal
E7G03	Wha	t is the typical input impedance of an op-amp?
	D	Very high
E7G04	Wha	t is meant by the term "op-amp input offset voltage"?
	C	The differential input voltage needed to bring the open loop output voltage to zero
E7G05	How	can unwanted ringing and audio instability be prevented in an op-amp RC audio filter circuit?
	.;	Restrict both gain and Q
E7C06	Wha	t is the gain-bandwidth of an operational amplifier?
E/G00	.i	The frequency at which the open-loop gain of the amplifier equals one
		The frequency at which the open-loop gain of the amplifier equals one
E7G07	:	t magnitude of voltage gain can be expected from the circuit in Figure E7 3 when R1 is 10 ohms and RI ohms?
	С	47
E7G08	How	does the gain of an ideal operational amplifier vary with frequency?
	D	It does not vary with frequency
E7G09	Wha	t will be the output voltage of the circuit shown in Figure E7-3 if R1 is 1000 ohms, RF is 10,000 ohms,
	and	0.23 volts DC is applied to the input?
	D	-2.3 volts
E7G10	:	t absolute voltage gain can be expected from the circuit in Figure E7-3 when R1 is 1800 ohms and RF i ilohms?
	С	38
E7G11	:	t absolute voltage gain can be expected from the circuit in Figure E7-3 when R1 is 3300 ohms and RF i
		ilohms? 14

		tors and signal sources: types of oscillators; synthesizers and phase-locked loops; direct digital synthesizers; ing thermal drift; microphonics; high-accuracy oscillators
E7H01	Wha	nt are three oscillator circuits used in amateur radio equipment?
	D	Colpitts, Hartley and Pierce
E7H02	Wha	at is a microphonic?
L	.i	Changes in oscillator frequency due to mechanical vibration
F71.00	D-	is positive feedback supplied in a Hartley assillator?
E7H03	.;	r is positive feedback supplied in a Hartley oscillator? Through a tapped coil
·	7	
E7H04	.j	is positive feedback supplied in a Colpitts oscillator?
	С	Through a capacitive divider
E7H05	How	is positive feedback supplied in a Pierce oscillator?
	D	Through a quartz crystal
E7H06	Whi	ch of the following oscillator circuits are commonly used in VFOs?
	.;	Colpitts and Hartley
	ъ.	con an assillatoria micronia managana ta madagana
E7H07	.j	Machanically isolate the essillator sircuitry from its enclosure
	D	Mechanically isolate the oscillator circuitry from its enclosure
E7H08	1	ch of the following components can be used to reduce thermal drift in crystal oscillators?
	A	NPO capacitors
E7H09	:	it type of frequency synthesizer circuit uses a phase accumulator, lookup table, digital to analog
		verter, and a low-pass anti-alias filter? A direct digital synthesizer
E7H10	.j	nt information is contained in the lookup table of a direct digital synthesizer (DDS)?
	В	Amplitude values that represent the desired waveform
E7H11	Wha	at are the major spectral impurity components of direct digital synthesizers?
.	С	Spurious signals at discrete frequencies
E7H12	Wh:	ch of the following must be done to ensure that a crystal oscillator provides the frequency specified by
<u> </u>	1	cn of the following must be done to ensure that a crystal oscillator provides the frequency specified by crystal manufacturer?
	В	Provide the crystal with a specified parallel capacitance
E7H13	Whi	ch of the following is a technique for providing highly accurate and stable oscillators needed for
		owave transmission and reception?
	D	All these choices are correct
E7H14	Wha	it is a phase-locked loop circuit?
1	.;	An electronic servo loop consisting of a phase detector, a low-pass filter, a voltage-controlled
		oscillator, and a stable reference oscillator
E7H15	Whi	ch of these functions can be performed by a phase-locked loop?
	D	Frequency synthesis, FM demodulation

E8: SIGNALS AND EMISSIONS

E8A: AC waveforms: sine, square, and irregular waveforms; AC measurements; average power and PEP of RF signals; Fourier analysis; analog to digital conversion: digital to analog conversion; advantages of digital communications E8A01 What is the name of the process that shows that a square wave is made up of a sine wave plus all its odd harmonics? Fourier analysis Which of the following is a type of analog-to-digital conversion? E8A02 Successive approximation What type of wave does a Fourier analysis show to be made up of sine waves of a given fundamental E8A03 frequency plus all its harmonics? A A sawtooth wave E8A04 What is "dither" with respect to analog-to-digital converters? A small amount of noise added to the input signal to allow more precise representation of a signal over time E8A05 What of the following instruments would be the most accurate for measuring the RMS voltage of a complex waveform? A true-RMS calculating meter What is the approximate ratio of PEP-to-average power in a typical single-sideband phone signal? E8A06 A 2.5 to 1 What determines the PEP-to-average power ratio of a single-sideband phone signal? E8A07 **B** Speech characteristics E8A08 Why would a direct or flash conversion analog-to-digital converter be useful for a software defined radio? Very high speed allows digitizing high frequencies E8A09 How many different input levels can be encoded by an analog-to-digital converter with 8-bit resolution? D 256 E8A10 What is the purpose of a low-pass filter used in conjunction with a digital-to-analog converter? C Remove harmonics from the output caused by the discrete analog levels generated E8A11 Which of the following is a measure of the quality of an analog-to-digital converter?

39 of 51 2/27/22, 16:13

Total harmonic distortion

r		ation and demodulation: modulation methods; modulation index and deviation ratio; frequency and time division lexing; Orthogonal Frequency Division Multiplexing			
E8B01	Wha	at is the modulation index of an FM signal?			
	Α	The ratio of frequency deviation to modulating signal frequency			
E8B02		y does the modulation index of a phase modulated emission yaws with DE carrier frequency?			
CODUZ		v does the modulation index of a phase-modulated emission vary with RF carrier frequency?			
		It does not depend on the RF carrier frequency			
E8B03		at is the modulation index of an FM-phone signal having a maximum frequency deviation of 3000 Hz eithers the continuous frequency when the modulating frequency is 1000 Hz			
	A	of the carrier frequency when the modulating frequency is 1000 Hz?			
		<u> </u>			
E8B04	:	at is the modulation index of an FM-phone signal having a maximum carrier deviation of plus or minus 6			
		when modulated with a 2 kHz modulating frequency?			
E8B05		at is the deviation ratio of an FM-phone signal having a maximum frequency swing of plus-or-minus 5 kH			
	whe	n the maximum modulation frequency is 3 kHz?			
	D	1.67			
EODOG	What is the deviation ratio of an FM-phone signal having a maximum frequency swing of plus or minus 7.5				
E8B06	Wha	at is the deviation ratio of an FM-phone signal having a maximum frequency swing of plus or minus 7.5			
E8B06	kHz	when the maximum modulation frequency is 3.5 kHz?			
E8B06	kHz				
	kHz A	when the maximum modulation frequency is 3.5 kHz? 2.14			
E8B06	kHz A Orti	when the maximum modulation frequency is 3.5 kHz?			
	kHz A Orti	when the maximum modulation frequency is 3.5 kHz? 2.14 nogonal Frequency Division Multiplexing is a technique used for which type of amateur communication?			
	kHz A Orti A	when the maximum modulation frequency is 3.5 kHz? 2.14 nogonal Frequency Division Multiplexing is a technique used for which type of amateur communication?			
E8B07	kHz A Orti A	when the maximum modulation frequency is 3.5 kHz? 2.14 nogonal Frequency Division Multiplexing is a technique used for which type of amateur communication? High-speed digital modes			
E8B07	kHz A Orti A Wha	when the maximum modulation frequency is 3.5 kHz? 2.14 nogonal Frequency Division Multiplexing is a technique used for which type of amateur communication? High-speed digital modes at describes Orthogonal Frequency Division Multiplexing? A digital modulation technique using subcarriers at frequencies chosen to avoid intersymbol			
E8B07	kHz A Orth A Wha	when the maximum modulation frequency is 3.5 kHz? 2.14 nogonal Frequency Division Multiplexing is a technique used for which type of amateur communication? High-speed digital modes at describes Orthogonal Frequency Division Multiplexing? A digital modulation technique using subcarriers at frequencies chosen to avoid intersymbol interference			
E8B07	kHz A Orth A Wha D	when the maximum modulation frequency is 3.5 kHz? 2.14 nogonal Frequency Division Multiplexing is a technique used for which type of amateur communication? High-speed digital modes at describes Orthogonal Frequency Division Multiplexing? A digital modulation technique using subcarriers at frequencies chosen to avoid intersymbol interference at is deviation ratio? The ratio of the maximum carrier frequency deviation to the highest audio modulating			
E8B07 E8B08	kHz A Orth A Wha D	when the maximum modulation frequency is 3.5 kHz? 2.14 nogonal Frequency Division Multiplexing is a technique used for which type of amateur communication? High-speed digital modes at describes Orthogonal Frequency Division Multiplexing? A digital modulation technique using subcarriers at frequencies chosen to avoid intersymbol interference at is deviation ratio? The ratio of the maximum carrier frequency deviation to the highest audio modulating frequency			
E8B07 E8B08	What B	when the maximum modulation frequency is 3.5 kHz? 2.14 nogonal Frequency Division Multiplexing is a technique used for which type of amateur communication? High-speed digital modes at describes Orthogonal Frequency Division Multiplexing? A digital modulation technique using subcarriers at frequencies chosen to avoid intersymbol interference at is deviation ratio? The ratio of the maximum carrier frequency deviation to the highest audio modulating frequency at is frequency division multiplexing? Two or more information streams are merged into a baseband, which then modulates the			

E8C: D	Digital signals: digital communication modes; information rate vs. bandwidth; error correction
E8C01	How is Forward Error Correction implemented?
k	C By transmitting extra data that may be used to detect and correct transmission errors
E8C02	
	C The rate at which the waveform changes to convey information
E8C03	Why should phase-shifting of a PSK signal be done at the zero crossing of the RF signal?
t	A To minimize bandwidth
f	
E8C04	
	C Use of sinusoidal data pulses
E8C05	What is the approximate bandwidth of a 13-WPM International Morse Code transmission?
<u>i</u>	C 52 Hz
E8C06	What is the bandwidth of a 170-hertz shift, 300-baud ASCII transmission?
	C 0.5 kHz
E8C07	What is the bandwidth of a 4800-Hz frequency shift, 9600-baud ASCII FM transmission?
	A 15.36 kHz
·	
E8C08	How does ARQ accomplish error correction?
	D If errors are detected, a retransmission is requested
E8C09	Which digital code allows only one bit to change between sequential code values?
L	D Gray code
f	
E8C10	How may symbol rate be increased without increasing bandwidth?
	C Using a more efficient digital code
E8C11	What is the relationship between symbol rate and baud?
	A They are the same
······	
E8C12	What factors affect the bandwidth of a transmitted CW signal?
	C Keying speed and shape factor (rise and fall time)

E8D01		are received spread spectrum signals resistant to interference?
	Α	Signals not using the spread spectrum algorithm are suppressed in the receiver
E8D02		it spread spectrum communications technique uses a high-speed binary bit stream to shift the phase of F carrier?
	В	Direct sequence
E8D03	How	does the spread spectrum technique of frequency hopping work?
	D	The frequency of the transmitted signal is changed very rapidly according to a pseudorandom sequence also used by the receiving station
E8D04	Wha	it is the primary effect of extremely short rise or fall time on a CW signal?
	С	The generation of key clicks
E8D05	Wha	at is the most common method of reducing key clicks?
	A	Increase keying waveform rise and fall times
F8D06	Wha	it is the advantage of including parity bits in ASCII characters?
E8D06	Wha D	ot is the advantage of including parity bits in ASCII characters? Some types of errors can be detected
	D	
	D	Some types of errors can be detected
E8D07	D Wha D	Some types of errors can be detected It is a common cause of overmodulation of AFSK signals?
E8D07	D Wha D	Some types of errors can be detected It is a common cause of overmodulation of AFSK signals? Excessive transmit audio levels
E8D07	D Wha D Wha	Some types of errors can be detected It is a common cause of overmodulation of AFSK signals? Excessive transmit audio levels It parameter evaluates distortion of an AFSK signal caused by excessive input audio levels?
E8D07	D Wha D Wha	Some types of errors can be detected It is a common cause of overmodulation of AFSK signals? Excessive transmit audio levels It parameter evaluates distortion of an AFSK signal caused by excessive input audio levels? Intermodulation Distortion (IMD)
E8D07 E8D08 E8D09	D Wha D Wha D Wha	Some types of errors can be detected It is a common cause of overmodulation of AFSK signals? Excessive transmit audio levels It parameter evaluates distortion of an AFSK signal caused by excessive input audio levels? Intermodulation Distortion (IMD) It is considered an acceptable maximum IMD level for an idling PSK signal?
E8D06 E8D07 E8D08 E8D09	D Wha D Wha D Wha	Some types of errors can be detected It is a common cause of overmodulation of AFSK signals? Excessive transmit audio levels It parameter evaluates distortion of an AFSK signal caused by excessive input audio levels? Intermodulation Distortion (IMD) It is considered an acceptable maximum IMD level for an idling PSK signal? -30 dB
E8D07 E8D08	D Wha D Wha D Wha B	Some types of errors can be detected It is a common cause of overmodulation of AFSK signals? Excessive transmit audio levels It parameter evaluates distortion of an AFSK signal caused by excessive input audio levels? Intermodulation Distortion (IMD) It is considered an acceptable maximum IMD level for an idling PSK signal? -30 dB It are some of the differences between the Baudot digital code and ASCII? Baudot uses 5 data bits per character, ASCII uses 7 or 8; Baudot uses 2 characters as

		E9: ANTENNAS AND TRANSMISSION LINES
A:	Basic A	Antenna parameters: radiation resistance, gain, beamwidth, efficiency; effective radiated power
E9A0	1 Wha	at is an isotropic antenna?
	С	A theoretical, omnidirectional antenna used as a reference for antenna gain
E9A0		at is the effective radiated power relative to a dipole of a repeater station with 150 watts transmitter er output, 2 dB feed line loss, 2.2 dB duplexer loss, and 7 dBd antenna gain?
	D	286 watts
E9A0	3 Wha	at is the radiation resistance of an antenna?
	C	The value of a resistance that would dissipate the same amount of power as that radiated from an antenna
E9A0	4 Whi	ch of the following factors affect the feed point impedance of an antenna?
	В	Antenna height
E9A0	5 Wha	it is included in the total resistance of an antenna system?
	D	Radiation resistance plus loss resistance
E9A0	6 Wha	It is the effective radiated power relative to a dipole of a repeater station with 200 watts transmitter
	pow	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain?
	A	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts
E9A0	7 Wha 2 di	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts
	A 7 Wha 2 di	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output If feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts
E9A0	A 7 Wha 2 di B 8 Wha	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output 3 feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth?
	A 7 Wha 2 di	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output If feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts
E9A0	A 7 Wha 2 de B 8 Wha B	rer output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts at is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output a feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts at is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement
	A 7 Wha 2 de B 8 Wha B	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth?
E9A0	A 7 Wha 2 de B 8 Wha B	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output is feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement It is antenna efficiency?
E9A0	A 7 Wha 2 de B 8 Wha B	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output is feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement It is antenna efficiency?
E9A0	A 7 Wha 2 de B 8 Wha B 9 Wha B	rer output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts ret is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output a feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts ret is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement ret is antenna efficiency? Radiation resistance divided by total resistance
E9A0	A 7 Wha 2 de B 8 Wha B 9 Wha B 0 Whi A	rer output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts at is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts at is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement at is antenna efficiency? Radiation resistance divided by total resistance ch of the following improves the efficiency of a ground-mounted quarter-wave vertical antenna? Installing a radial system
E9A04	A 7 Wha 2 de B 8 Wha B 9 Wha B 0 Whi A	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement at is antenna efficiency? Radiation resistance divided by total resistance Installing a radial system Ch of the following factors determines ground losses for a ground-mounted vertical antenna operating in
E9A04	A 7 What 2 de B 8 What B 9 What B 1 Whithe C 2 How	rer output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement it is antenna efficiency? Radiation resistance divided by total resistance Ch of the following improves the efficiency of a ground-mounted quarter-wave vertical antenna? Installing a radial system Ch of the following factors determines ground losses for a ground-mounted vertical antenna operating in 3 MHz to 30 MHz range?
E9A0: E9A1: E9A1:	A 7 What 2 de B 8 What B 9 What B 1 Whithe C 2 How isot	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement it is antenna efficiency? Radiation resistance divided by total resistance Installing a radial system Ch of the following improves the efficiency of a ground-mounted quarter-wave vertical antenna? Installing a radial system Ch of the following factors determines ground losses for a ground-mounted vertical antenna operating in 3 MHz to 30 MHz range? Soil conductivity The following decorate determines ground losses for a ground-mounted vertical antenna operating in 3 MHz to 30 MHz range?
E9A0: E9A1: E9A1:	A 7 What 2 de B 8 What B 9 What B 1 Whithe C 2 How isot	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement It is antenna efficiency? Radiation resistance divided by total resistance Installing a radial system Ch of the following improves the efficiency of a ground-mounted quarter-wave vertical antenna? Installing a radial system Ch of the following factors determines ground losses for a ground-mounted vertical antenna operating in 3 MHz to 30 MHz range? Soil conductivity The following does an antenna have compared to a 1/2-wavelength dipole when it has 6 dB gain over an repic antenna?
E9A0: E9A1: E9A1:	A 7 What 2 dis B 8 What B 9 What B 1 Whithe C 2 How isot A	er output, 4 dB feed line loss, 3.2 dB duplexer loss, 0.8 dB circulator loss, and 10 dBd antenna gain? 317 watts It is the effective isotropic radiated power of a repeater station with 200 watts transmitter power output feed line loss, 2.8 dB duplexer loss, 1.2 dB circulator loss, and 7 dBi antenna gain? 252 watts It is antenna bandwidth? The frequency range over which an antenna satisfies a performance requirement It is antenna efficiency? Radiation resistance divided by total resistance Installing a radial system Ch of the following improves the efficiency of a ground-mounted quarter-wave vertical antenna? Installing a radial system Ch of the following factors determines ground losses for a ground-mounted vertical antenna operating in 3 MHz to 30 MHz range? Soil conductivity The following does an antenna have compared to a 1/2-wavelength dipole when it has 6 dB gain over an repic antenna?

E9B: /	Antenna patterns and designs: E and H plane patterns; gain as a function of pattern; antenna modeling
E9B01	In the antenna radiation pattern shown in Figure E9-1, what is the beamwidth?
	B 50 degrees
E9B02	In the antenna radiation pattern shown in Figure E9-1, what is the front-to-back ratio?
Laboz	B 18 dB
E9B03	In the antenna radiation pattern shown in Figure E9-1, what is the front-to-side ratio?
	B 14 dB
E9B04	What is the front-to-back ratio of the radiation pattern shown in Figure E9 2?
L3D04	B 28 dB
E9B05	What type of antenna pattern is shown in Figure E9-2?
	A Elevation
E9B06	What is the elevation angle of peak response in the antenna radiation pattern shown in Figure E9-2?
E9B00	C 7.5 degrees
	c /i.o degrees
E9B07	How does the total amount of radiation emitted by a directional gain antenna compare with the total amount
	of radiation emitted from a theoretical isotropic antenna, assuming each is driven by the same amount of power?
	C They are the same
·	
E9B08	What is the far field of an antenna?
	D The region where the shape of the antenna pattern is independent of distance
E9B09	What type of computer program technique is commonly used for modeling antennas?
<u> </u>	B Method of Moments
;	
E9B10	What is the principle of a Method of Moments analysis?
	A wire is modeled as a series of segments, each having a uniform value of current
E9B11	What is a disadvantage of decreasing the number of wire segments in an antenna model below 10 segments
	in the state of a second of a contracting the number of which segments in an antenna model below to segments
Labii	per half-wavelength?

2/27/22, 16:13

E9C01		t is the radiation pattern of two $1/4$ -wavelength vertical antennas spaced $1/2$ -wavelength apart and fed degrees out of phase?
	D	A figure-8 oriented along the axis of the array
E9C02		t is the radiation pattern of two 1/4 wavelength vertical antennas spaced 1/4 wavelength apart and fed egrees out of phase?
		Cardioid
E9C03	:	it is the radiation pattern of two 1/4-wavelength vertical antennas spaced 1/2 wavelength apart and fed nase?
	С	A Figure-8 broadside to the axis of the array
E9C04	Wha	t happens to the radiation pattern of an unterminated long wire antenna as the wire length is increased
E9C04		The lobes align more in the direction of the wire
E9C05	Whi	ch of the following is a type of OCFD antenna?
	Α	A dipole fed approximately 1/3 the way from one end with a 4:1 balun to provide multiband operation
E9C06	Wha	t is the effect of adding a terminating resistor to a rhombic antenna?
	! B	It changes the radiation pattern from bidirectional to unidirectional
E9C07	Wha	t is the approximate feed point impedance at the center of a two-wire folded dipole antenna?
	Α	300 ohms
E9C08	Wha	t is a folded dipole antenna?
	С	A half-wave dipole with an additional parallel wire connecting its two ends
E9C09	Whi	ch of the following describes a G5RV antenna?
LJCOJ		A multi-band dipole antenna fed with coax and a balun through a selected length of open wire
		transmission line
E9C10	Whi	ch of the following describes a Zepp antenna?
	В	An end-fed dipole antenna
	.	to the first of the late of the section of the late of
E9C11	!	is the far-field elevation pattern of a vertically polarized antenna affected by being mounted over vater versus soil?
	D	The low-angle radiation increases
E9C12	\A/bi	ch of the following describes an Extended Double 7cm automa?
E9C12		ch of the following describes an Extended Double Zepp antenna?
	С	A center-fed 1.25-wavelength antenna (two 5/8-wave elements in phase)
E9C13		does the radiation pattern of a horizontally polarized 3-element beam antenna vary with increasing ht above ground?
	_	The takeoff angle of the lowest elevation lobe decreases

E9D01	How	much does the gain of an ideal parabolic dish antenna change when the operating frequency is doubled
	J	6 dB
	•	U UB
E9D02	How	can linearly polarized Yagi antennas be used to produce circular polarization?
	С	Arrange two Yagis perpendicular to each other with the driven elements at the same point on the boom fed 90 degrees out of phase
E9D03	Whe	re should a high Q loading coil be placed to minimize losses in a shortened vertical antenna?
	Α	Near the center of the vertical radiator
E9D04	Why	should an HF mobile antenna loading coil have a high ratio of reactance to resistance?
	С	To minimize losses
E9D05	Wha	t usually occurs if a Yagi antenna is designed solely for maximum forward gain?
		The front-to-back ratio decreases
		``````````````````````````````````````
E9D06	1	t happens to the SWR bandwidth when one or more loading coils are used to resonate an electrically t antenna?
	В	It is decreased
E9D07	Wha	t is an advantage of using top loading in a shortened HF vertical antenna?
	D	Improved radiation efficiency
E9D08	Wha	t happens as the Q of an antenna increases?
		SWR bandwidth decreases
	Wha	t is the function of a loading coil used as part of an HF mobile antenna?
E9D09	D	To cancel capacitive reactance
E9D09	_	
E9D09	7	t hannens to feed-point impedance at the base of a fixed length HF mobile antenna when operated belo
	Wha	t happens to feed-point impedance at the base of a fixed length HF mobile antenna when operated belo esonant frequency?
	Wha	t happens to feed-point impedance at the base of a fixed length HF mobile antenna when operated beloesonant frequency? The radiation resistance decreases and the capacitive reactance increases
E9D10	Wha its r	The radiation resistance decreases and the capacitive reactance increases
E9D10 E9D11	Whate its read B	esonant frequency?

<u> </u>	atching: matching antennas to feed lines; phasing lines; power dividers	
E9E01	What system matches a higher-impedance transmission line to a lower-impedance antenna by connection to the driven element in two places spaced a fraction of a wavelength each side of element cente	_
	B The delta matching system	
E9E02	What is the name of an antenna matching system that matches an unbalanced feed line to an antenna feeding the driven element both at the center of the element and at a fraction of a wavelength to one center?	
	A The gamma match	
E9E03	What is the name of the matching system that uses a section of transmission line connected in parallo the feed line at or near the feed point?	el with
	D The stub match	
E9E04	What is the purpose of the series capacitor in a gamma-type antenna matching network?	
	B To cancel the inductive reactance of the matching network	
E9E05	How must an antenna's driven element be tuned to use a hairpin matching system?	
	A The driven element reactance must be capacitive	
E9E06	Which of these feed line impedances would be suitable for constructing a quarter-wave Q-section for matching a 100-ohm loop to 50-ohm feed line?	
	C 75 ohms	
E9E07	What parameter describes the interactions at the load end of a mismatched transmission line?  B Reflection coefficient	
E9E08	What is a use for a Wilkinson divider?	
	C It is used to divide power equally between two 50-ohm loads while maintaining 50-ohm impedance	input
E9E09	Which of the following is used to shunt-feed a grounded tower at its base?	
	C Gamma match	
E9E10	Which of these choices is an effective way to match an antenna with a 100-ohm feed point impedance 50-ohm coaxial cable feed line?	e to a
	C Insert a 1/4-wavelength piece of 75-ohm coaxial cable transmission line in series between antenna terminals and the 50-ohm feed cable	een th
E9E11	What is the primary purpose of phasing lines when used with an antenna having multiple driven elem	ents?
	A It ensures that each driven element operates in concert with the others to create the de antenna pattern	

E9F01	What is the velocity factor of a transmission line?
	D The velocity of the wave in the transmission line divided by the velocity of light in a vacuum
E9F02	Which of the following has the biggest effect on the velocity factor of a transmission line?
	C Dielectric materials used in the line
E9F03	Why is the physical length of a coaxial cable transmission line shorter than its electrical length?
23.03	D Electrical signals move more slowly in a coaxial cable than in air
E9F04	What impedance does a 1/2-wavelength transmission line present to a generator when the line is shorted the far end?
	B Very low impedance
E9F05	What is the approximate physical length of a solid polyethylene dielectric coaxial transmission line that is
LJ1 03	electrically 1/4 wavelength long at 14.1 MHz?
	D 3.5 meters
E9F06	What is the approximate physical length of an air-insulated, parallel conductor transmission line that is
	electrically 1/2 wavelength long at 14.10 MHz?
	C 10.6 meters
E9F07	How does ladder line compare to small-diameter coaxial cable such as RG-58 at 50 MHz?
	A Lower loss
E9F08	Which of the following is a significant difference between foam dielectric coaxial cable and solid dielectric cable, assuming all other parameters are the same?
	D All these choices are correct
E9F09	What is the approximate physical length of a foam polyethylene dielectric coaxial transmission line that is electrically 1/4 wavelength long at 7.2 MHz?
	B 8.3 meters
E9F10	What impedance does a 1/8-wavelength transmission line present to a generator when the line is shorted the far end?
	C An inductive reactance
E9F11	What impedance does a $1/8$ -wavelength transmission line present to a generator when the line is open at far end?
	C A capacitive reactance
E9F12	What impedance does a $1/4$ -wavelength transmission line present to a generator when the line is open at far end?
	D Very low impedance
E9F13	What impedance does a 1/4-wavelength transmission line present to a generator when the line is shorted
レン・エン	$\pm$

E9G: T	he Sr	nith chart
E9G01	Whi	ch of the following can be calculated using a Smith chart?
<b>1</b>	Α	Impedance along transmission lines
F0C03	\A/b-	at time of accordinate quatem is used in a Corith shout?
E9G02	<b>.</b> !	It type of coordinate system is used in a Smith chart?  Resistance circles and reactance arcs
	В	Resistance circles and reactance arcs
E9G03	Whi	ch of the following is often determined using a Smith chart?
	С	Impedance and SWR values in transmission lines
E9G04	Wha	at are the two families of circles and arcs that make up a Smith chart?
	С	Resistance and reactance
E9G05	Whi	ch of the following is a common use for a Smith chart?
		Determine the length and position of an impedance matching stub
E9G06	arcs	the Smith chart shown in Figure E9-3, what is the name for the large outer circle on which the reactance terminate?  Reactance axis
E9G07	On t	he Smith chart shown in Figure E9-3, what is the only straight line shown?
<b>i</b>	D	The resistance axis
E9G08	Wha	at is the process of normalization with regard to a Smith chart?
	С	Reassigning impedance values with regard to the prime center
E9G09	Wha	at third family of circles is often added to a Smith chart during the process of solving problems?
		Standing wave ratio circles
E9G10	Wha	at do the arcs on a Smith chart represent?
	D	Points with constant reactance
E9G11	How	are the wavelength scales on a Smith chart calibrated?
i	<b>.</b> j	In fractions of transmission line electrical wavelength

	Receiv Intenn	ng Antennas: radio direction finding antennas; Beverage antennas; specialized receiving antennas; long-wire receivin as
E9H01		en constructing a Beverage antenna, which of the following factors should be included in the design to eve good performance at the desired frequency?
	D	It should be one or more wavelengths long
E9H02	Whi	ch is generally true for low band (160 meter and 80 meter) receiving antennas?
L	Α	Atmospheric noise is so high that gain over a dipole is not important
E9H03	Wha	t is Receiving Directivity Factor (RDF)?
	D	Forward gain compared to average gain over the entire hemisphere
E9H04	:	nt is an advantage of placing a grounded electrostatic shield around a small loop direction-finding enna?
	В	It eliminates unbalanced capacitive coupling to the surroundings, improving the nulls
E9H05		t is the main drawback of a small wire-loop antenna for direction finding? It has a bidirectional pattern
E9H06	!	It is the triangulation method of direction finding?  Antenna headings from several different receiving locations are used to locate the signal
		source
E9H07	Why	is RF attenuation used when direction-finding?
	D	To prevent receiver overload which reduces pattern nulls
E9H08	Wha	at is the function of a sense antenna?
	Α	It modifies the pattern of a DF antenna array to provide a null in one direction
E9H09	Wha	et is a Pennant antenna?
	В	A small, vertically oriented receiving antenna consisting of a triangular loop terminated in approximately 900 ohms
E9H10	How	can the output voltage of a multiple-turn receiving loop antenna be increased?
	D	By increasing the number of turns and/or the area
E9H11	Wha	nt feature of a cardioid pattern antenna makes it useful for direction finding?
	В	A very sharp single null

		E0: SAFETY -
۹: ۶	Safety	: RF radiation hazards; hazardous materials; grounding
E0A01	Wha	at is the primary function of an external earth connection or ground rod?
	В	Lightning protection
E0A02		en evaluating RF exposure levels from your station at a neighbor's home, what must you do?
	В	Ensure signals from your station are less than the uncontrolled Maximum Permitted Exposure (MPE) limits
E0A03	Ove	r what range of frequencies are the FCC human body RF exposure limits most restrictive?
	С	30 to 300 MHz
E0A04		en evaluating a site with multiple transmitters operating at the same time, the operators and licensees o ch transmitters are responsible for mitigating over-exposure situations?
	С	Each transmitter that produces 5 percent or more of its MPE limit in areas where the total MPE limit is exceeded.
E0A05	Wha	at is one of the potential hazards of operating in the amateur radio microwave bands?
	В	The high gain antennas commonly used can result in high exposure levels
E0A06	Why	r are there separate electric (E) and magnetic (H) field MPE limits?
	D	All these choices are correct
E0A07	Hov	may dangerous levels of carbon monoxide from an emergency generator be detected?
	В	Only with a carbon monoxide detector
E0A08	Wha	at does SAR measure?
	С	The rate at which RF energy is absorbed by the body
E0A09		ch insulating material commonly used as a thermal conductor for some types of electronic devices is emely toxic if broken or crushed and the particles are accidentally inhaled?
	С	Beryllium Oxide
E0A10	Wha	at toxic material may be present in some electronic components such as high voltage capacitors and
	:	sformers?
	Α	Polychlorinated biphenyls
E0A11	Whi	ch of the following injuries can result from using high-power UHF or microwave transmitters?
		Localized heating of the body from RF exposure in excess of the MPE limits